

# SWEETHEART TEA LIGHT HOLDERS



6

Designs

# THREAD LIST



## Isacord Thread Colors

---

0015 White  
1900 Geranium  
1912 Winterberry

**\* Project instructions included after design list.**

**Note: One spool of 1000 meter thread is adequate for the project unless otherwise noted.**

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



**12661-01 Heart 1 Tea Light Holder FSL**

Size Inches:                      Size mm:                      Stitch Count:  
 4.26 X 8.25 in.    108.20 X 209.55 mm    95,642 St.

- 1. Inner Heart Lace Fills ..... 1900
- 2. Inner Heart Dark Red Lace Fills ..... 1912
- 3. Red Lace Fills ..... 1900
- 4. White Lace Fills and Satins ..... 0015
- 5. Dark Red Lace Satins ..... 1912




**12661-02 Love Tea Light Holder FSL**

Size Inches:                      Size mm:                      Stitch Count:  
 3.78 X 8.25 in.    96.01 X 209.55 mm    87,743 St.

- 1. Red Lace Fills ..... 1900
- 2. Dark Red Lace Fills and Satins ..... 1912
- 3. Letters Red Lace Fills ..... 1900
- 4. Letters White Satins ..... 0015

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



**12661-03 Heart 2 Tea Light Holder FSL**

Size Inches:	Size mm:	Stitch Count:
2.33 X 8.25 in.	59.18 X 209.55 mm	55,510 St.

- 1. Dark Red Lace Fills ..... 1912
- 2. Red Lace Fills and Satins ..... 1900



**12661-04 Soul Mates Tea Light Holder FSL**

Size Inches:	Size mm:	Stitch Count:
4.46 X 8.25 in.	113.28 X 209.55 mm	99,341 St.

- 1. Dark Red Lace Fills ..... 1912
- 2. Red Lace Fills ..... 1900
- 3. White Lace Fills and Satins ..... 0015

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



**12661-05 Be Mine Tea Light Holder FSL**

Size Inches:            Size mm:            Stitch Count:  
 3.93 X 8.25 in.    99.82 X 209.55 mm    89,197 St.

- 1. Red Lace Fills and Satins..... 1900
- 2. Letters White Lace Fills ..... 0015
- 3. Letters Dark Red Lace Satins..... 1912



**12661-06 XOXO Tea Light Holder FSL**

Size Inches:            Size mm:            Stitch Count:  
 3.15 X 8.25 in.    80.01 X 209.55 mm    74,027 St.


- 1. White Lace Fills and Satins ..... 0015
- 2. Dark Red Lace Fills ..... 1912
- 3. Red Lace Fills and Satins..... 1900
- 4. Letters Lace Satins..... 0015

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

## 12661-07 Tea Light Holder Base FSL

Size Inches:	Size mm:	Stitch Count:
2.96 X 2.94 in.	75.18 X 74.68 mm	8,441 St.

■ 1. Single Color Design..... 0020



# COLLECTION SUPPLIES



## Stabilizers

- OESD AquaMesh WashAway
- OESD BadgeMaster WashAway

## Notions & Tools

- Embroidery Needle Ballpoint 80/12
- OESD Alligator Clamps
- OESD Button Clips
- OESD Grippy Grid
- OESD Perfect Embroidery Press Cloth

## Isacord Thread Colors

- As per thread chart
- Match bobbin thread to top thread

## Stabilizer

- OESD AquaMesh
- OESD BadgeMaster

## Notions/Tools

- 80/12 Embroidery Ballpoint Titanium needle for extended needle life
- OESD Alligator Clamps
- OESD Button Clips
- OESD Perfect Point and Press Tool

## Isacord Thread Colors

- All OESD designs are digitized with Isacord 40 wt. polyester thread as the top thread and in the bobbin.
- Refer to the thread chart for color specifications.
- Match bobbin thread color to the top thread.

## Instructions

### Step 1 - Hoop

For FSL structures, hoop one layer of OESD AquaMesh and one layer of OESD BadgeMaster. BadgeMaster contains more starch so, combined with the AquaMesh, the lace is more rigid. For other FSL, where a softer lace is desired, hoop two layers of AquaMesh.

### Step 2 - Embroider

Stitch the design per the thread chart with matching thread in the bobbin at each color change. When complete, remove from the hoop and trim away excess stabilizer about 1/4"-1/2" from the stitching.

### Step 3 - Rinse

Rinse remaining stabilizer out in warm running water. For stiffer lace and FSL structures, DO NOT rinse away all of the stabilizer. The lace should be just slightly tacky. For softer lace, rinse until all traces of the stabilizer are removed.

### Step 4 - Dry

Lay right side down flat on a non-stick surface, such as a cooling rack, parchment paper or Teflon sheet. This minimizes the tendency for the lace to curl. Let the pieces dry completely before proceeding with any assembly.

### Step 5 - Press

Once completely dry, press right side down on a OESD Perfect Embroidery Press Cloth.

### Step 6 - Assemble Structure

Note: Specific assembly instructions for a design/collection may be found in the thread chart pdf following the individual design color charts.

Lace must be COMPLETELY DRY before assembly. Wetting the buttonettes or eyelets to assemble is not recommended and may result in them stretching and coming "unbuttoned" when dry.

Use a pair of OESD Alligator Clamps to insert the buttonettes into the eyelets. Insert the tip of the OESD Alligator Clamps into the eyelet, grasp the buttonette and pull through the eyelet. Alternatively, use a stiletto or tweezers to push the buttonette through the eyelet.

## Helpful Tips

### Limp Lace

If the design is not stiff enough, press the lace pieces on the wrong side while applying spray starch. After ironing, spray again with starch and allow to dry completely. This will stiffen the lace pieces nicely and aid in construction. Or easily re-stiffen by diluting some stabilizer scraps in water (or use liquid starch) and dipping the item in the solution. Lay flat to dry.

### Eyelets Too Small

If any of the eyelets appear closed or too small to penetrate with Alligator Clamps, they may be stretched by inserting the small end of the OESD Perfect Point and Press Tool into the eyelet opening and stretching it open wide enough to accommodate the OESD Alligator Clamps.

### Button Clips

During the assembly process, some structures pull on buttonettes that have already been inserted and could pull them out altogether. Putting a Button Clip on the assembled buttonette will keep it in position during the assembly process. Remove the Button Clips when the assembly is complete.

### Alternative Construction Option

In some cases, the buttonettes may be pulled to the inside of a project, instead of being visible on the outside. Insert the OESD Alligator Clamps through the eyelet from the wrong, or inside, of the lace and grasp the corresponding buttonette. Pull the buttonette to the wrong side of the lace.

Pulling the buttonettes to the inside may cause stress on the ones already done. Button clips may be placed on the completed buttonette(s) to prevent them from pulling out of the eyelet during construction.



# EMBROIDERY



## STEP 1

- Hoop one layer of OESD AquaMesh and one layer of OESD BadgeMaster.
- Attach the hoop to the machine.
- Load the tea light holder design.
- Design used for demonstration purpose is 12661-01 Heart 1 Tea Light Holder FSL.



## STEP 2

- Stitch the design per the thread chart with matching thread in the bobbin at each color change.
- Remove the hoop from the machine and the design from the hoop.
- Trim excess stabilizer 1/4"-1/2" from the design.



## STEP 3

- Rinse each piece in warm running water until the design is only slightly tacky.
- Dry completely.



# ASSEMBLY




## STEP 4

- Once dry, press right side down on a Perfect Embroidery Press Cloth.



## STEP 5

- Match the eyelets to the buttonettes. Pull each buttonette through the corresponding eyelet.
- Attach a button clip to hold the buttonettes in place temporarily when needed.



# ASSEMBLY



## STEP 6

- Add a tea light to create a glow.

