


#12778



**4**  
DESIGNS

## In The Hoop Binder Zipper Pouches

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.




## 12778-01 ITH School Supplies Pouch

Size Inches:                      Size mm:                      Stitch Count:  
 6.30 X 10.62 in.    160.02 X 269.75 mm    10,082 St.

■ 1. Zipper Placement Stitch .....	1375
■ 2. Zipper Tackdown .....	1375
■ 3. Front Panel Top Tackdown and Grommet Guides .....	1375
■ 4. Front Panel Bottom Tackdown .....	1375
■ 5. Design Detail .....	1375
■ 6. Seam Stitch .....	0672



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



## 12778-02 ITH Odds & Ends Pouch

Size Inches:                      Size mm:                      Stitch Count:  
 6.33 X 10.70 in.    160.78 X 271.78 mm    10,349 St.


















<input type="checkbox"/>	1. Zipper Placement Stitch .....	0015
<input type="checkbox"/>	2. Zipper Tackdown .....	0015
<input type="checkbox"/>	3. Front Panel Top Tackdown and Grommet Guide.....	0015
<input type="checkbox"/>	4. Front Panel Bottom Tackdown .....	0015
<input checked="" type="checkbox"/>	5. Blue Linework.....	4332
<input checked="" type="checkbox"/>	6. Red Linework .....	1725
<input checked="" type="checkbox"/>	7. Black Linework .....	4174
<input checked="" type="checkbox"/>	8. Lettering .....	4174
<input type="checkbox"/>	9. Seam Stitch.....	0015

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



## 12778-03 ITH Sewing Supplies Pouch

Size Inches:                      Size mm:                      Stitch Count:  
 6.30 X 10.63 in.    160.02 X 270.00 mm    24,867 St.

	1. Zipper Placement Stitch .....	2170
	2. Zipper Tackdown .....	2170
	3. Front Panel Top Tackdown and Grommet Guides .....	2170
	4. Front Panel Bottom Tackdown .....	4952
	5. Yellow Detail .....	0310
	6. Silver Detail .....	0151
	7. Scissor Handles .....	2550
	8. Dark Blue Thread .....	3510
	9. Spool Ends .....	1123
	10. Design Outlines .....	1375
	11. Leaves .....	5633
	12. Red Button and Cushion .....	1725
	13. Yarn and Dark Pink Flowers .....	2521
	14. Light Pink Button and Flowers .....	2051
	15. Light Blue Buttons .....	3630
	16. Design Outlines .....	1375
	17. Seam Stitch .....	0015



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



## 12778-04 ITH Blank Pouch

Size Inches:                      Size mm:                      Stitch Count:  
 6.30 X 10.62 in.    160.02 X 269.75 mm    3,598 St.

- 1. Zipper Placement Stitch .....0020
- 2. Zipper Tackdown .....0020
- 3. Front Panel Top Tackdowns and Grommet Guides .....0020
- 4. Front Panel Bottom Tackdown .....0020
- 5. Seam Stitch .....0020

# MATERIALS



## Stabilizer

- OESD Ultra Clean and Tear Stabilizer

## Supplies

- Embroidery thread
- Fabric
- 12" - 14" nylon coil zipper
- 3 - ¼" Grommets
- Grommet Pliers
- Expert Embroidery Tape TearAway

## Isacord Thread Colors


0015 White	1375 Dark Charcoal	3510 Electric Blue
0020 Black	1725 Terra Cotta	3630 Sweet Boy
0151 Cloud	2051 Teaberry	4174 Charcoal
0310 Yellow	2170 Chiffon	4332 Rough Sea
0672 Baquette	2521 Fuschia	4952 Mystic Ocean
1123 Caramel Cream	2550 Soft Pink	5633 Lime

# EMBROIDERY



## STEP 1

- Cut Top Panel = 13" x 6" fold to create 13" x 3"
- Cut Bottom Front Panel & lining = 13" x 12" fold to create 13"x 6"
- Cut Back Panel & lining = 13" x 8"




## STEP 2

- With temporary adhesive, lightly spray and adhere the two 13" x 8" linings, wrong sides together.



## STEP 3

- Hoop 1 sheet of OESD Ultra Clean and Tear Stabilizer.
- Sew Color #1 Zipper Placement Stitch.



# EMBROIDERY



## STEP 4

- Place zipper between the Placement Stitches and use OESD Expert Embroidery Tape to secure the zipper to the stabilizer
- Sew color #2 Zipper Tackdown.



## STEP 5

- Place Top Panel along the zipper teeth, be careful not to cover the teeth.
- Sew color #3 Front Panel Top Tackdown and Grommet Guide.



## STEP 6

- Place Bottom Panel along the zipper teeth be careful not to cover the teeth.





# INSTRUCTIONS




## STEP 7

- Flip hoop over, lightly spray temporary adhesive and place the Bottom Lining over the Front Panel careful not to cover zipper.




## STEP 8

- Sew color #4 Front Panel Bottom Tackdown.



## STEP 9

- Embroider design work.




# INSTRUCTIONS



## STEP 10

- After design work is embroidered and before the next step, make sure to UNZIP THE ZIPPER and replace your OESD Expert Embroidery Tape.



## STEP 11

- Place Back Panel face down with the lining face up. Make sure to completely cover the design.



## STEP 12

- Sew last color Seam Stitch.



# INSTRUCTIONS




## STEP 13

- Remove design from the hoop and trim close to the seam stitch, avoid cutting the seam stitches.



## STEP 14

- Flip the design over and remove the stabilizer from around the zipper.



## STEP 15

- Unzip the zipper and turn the pouch right side out. Carefully use a chopstick or pencil to help poke out corners.





# INSTRUCTIONS




## STEP 16

- With a zipper foot and using the Top Panel Tackdown stitches as a guide, sew the top panel to the back. This will help in the installation of the grommets as well as keep objects in the bottom section of the pouch.




## STEP 17

- Using a utility knife or trimming scissors, cut holes through all the layers of fabric at the Grommet Placement guides.



## STEP 18

- Insert the Male end of the grommet through the front of the pouch.



# INSTRUCTIONS



## STEP 19

- Flip the pouch over and insert the Female end of the grommet through the back of the pouch and press. Repeat for the remaining grommet guides.

