

Boo Manor Tiling Scene by Michael Zindell



Collection No. 80401 1 Design/9 Files MATERIALS



Isacord Thread Colors

0015 White

0020 Black

0108 Cobblestone

0270 Buttercream

0700 Bright Yellow

1102 Pumpkin

1311 Date

1321 Dark Orange

1332 Harvest

1334 Spice

2900 Deep Purple

2920 Purple

3040 Lavender

3110 Dark Ink

3355 Dark Indigo

3450 Lavender

3971 Silver

Note: One spool of 1000 meter thread is adequate for the project unless otherwise noted.

MATERIALS



Stabilizers

- OESD Heavy Weight TearAway
- OESD Ultra Clean and Tear TearAway
- OESD Fusible Woven
- OESD SoftWeb

 Note: Select white or black Fusible Woven based on fabric choice: white for medium to light colored fabrics and black for dark colored fabrics.

Fabrics/Textiles

Background:

Navy Quilter's Cotton
 1 1/2 yard

Appliques:

- Purple Quilter's Cotton
 1/4 yard
- Orange Quilter's Cotton
 1/4 yard
- White Quilter's Cotton 10" square
- Black Quilter's Cotton
 5" x 8"

- Batting 26" x 21"
- Backing
 2/3 yard
- Binding
 1/4 yard (based on 2 1/2" wide binding strips)
- Note: Fabric amounts
 are estimates and may
 result in overages.
 Background fabric
 yardage is based on a
 11" x 15" hooping. Fabric
 and stabilizer amounts
 may vary depending on
 hoop size and number
 of tiles per hooping.

Notion & Tools

- OESD Grippy Grid
- OESD Perfect Embroidery Press Cloth
- OESD Expert Point and Press Too
- OESD Expert Embroidery Tape TearAway
- 505 Temporary Spray Adhesive
- Ruler, rotary cutter, mat

- Contrasting bobbin thread (seam stitch only, may be different colors)
- Fabric marking pen
- Walking foot or Dual feed foot
- Embroidery Needle Sharp 75/11
- Sharp 90/14 for quilting

Isacord Thread Colors

· Per thread chart

SUMMARY



Completed Tiling Scene Size: 21" H x 16" W



Largest Tile Size: 7.40 in. X 5.97 in.

EMBROIDERY OF



General Instructions

Embroider one of each design file 80401-01 through 80401-09.

Design 80401-08 is shown in the instructions.

For each hooping, cut the following 11" x 15", or large enough to hoop:

- 1 layer of background fabric
- 1 layer of OESD Fusible Woven, black
- 1 layer of OESD Heavy Weight TearAway
- 1 layer of OESD Ultra Clean and Tear TearAway

Note: To economize on fabric, cut the fabric 15" wide (or the height of the hoop + 2") x the width of the fabric. Apply the stabilizers. Move the hoop down the length of the fabric as each tile is stitched. Leave a minimum of 1 1/2" between the tiles. This is called chain hooping.

Applique technique shown is cut in place. Pre-cut applique patterns are included at the end of the instructions.

Step 1

 Apply black OESD Fusible Woven to the back of the background fabric, per the product directions.





EMBROIDERY OF



Step 2

- Cut the applique fabric 1/4" 1/2" larger than the applique pattern. The applique patterns are included at the end of the instructions.
- Adhere one layer of SoftWeb to the wrong side of the applique fabric to provide body to the fabric.
- Note: To prevent the background fabric from shadowing through the applique fabric, apply white Fusible Woven to the back of the fabric before SoftWeb. The white applique fabric, shown in the instructions, has Fusible Woven applied.





- Apply one layer of OESD Heavy Weight TearAway and one layer of OESD Ultra Clean and Tear to the wrong side of the background fabric with 505 Temporary Spray Adhesive.
- Using the OESD Grippy Grid, hoop fabric and stabilizer.





Step 4

- Load the selected design into the machine.
- Example design is 80401-08.
- Thread the machine per the thread chart.
- · Place the hoop on the machine.
- Stitch Machine Step 1, Black Fabric Placement Stitch.



Step 5

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Remove the paper backing off the SoftWeb on the black fabric.
- Completely cover the placement stitch with the prepared black applique fabric.
- Tape in place with OESD Expert Embroidery Tape TearAway to secure.



- Return the hoop to the machine.
- Stitch Machine Step 2, Cut Line and Tackdown.





Step 7

- Remove the hoop from the machine, but NOT the project from the hoop.
- Trim the excess fabric as close to the cut line as possible. If the outermost stitches (cut line) are cut, the inner stitches (tackdown) will hold the applique in place.



Step 8

- Return the hoop to the machine.
- Stitch Machine Step 3, Orange Fabric Placement Stitch.



Step 9


- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Completely cover the placement stitch with the prepared orange applique fabric.
- Tape in place to secure.





Step 10

- Return the hoop to the machine.
- Stitch Machine Step 4, Cut Line and Tackdown.



Step 11

- Remove the hoop from the machine, but NOT the project from the hoop.
- Trim the excess fabric as close to the cut line as possible.



- Return the hoop to the machine.
- Stitch Machine Step 5, Purple Fabric Placement Stitch.





Step 13

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Completely cover the placement stitch with the prepared purple applique fabric.
- Tape in place to secure.



Step 14

- Return the hoop to the machine.
- Stitch Machine Step 6, Cut Line and Tackdown.



- Remove the hoop from the machine, but NOT the project from the hoop.
- Trim the excess fabric as close to the cut line as possible.





Step 16

- Return the hoop to the machine.
- Stitch Machine Step 7, White Fabric Placement Stitch.



Step 17

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Completely cover the placement stitch with the prepared white applique fabric.
- Tape in place to secure.



- · Return the hoop to the machine.
- Stitch Machine Step 8, Cut Line and Tackdown.





Step 19

- Remove the hoop from the machine, but NOT the project from the hoop.
- Trim the excess fabric as close to the cut line as possible.



Step 20

- · Return the hoop to the machine.
- Stitch the remaining steps per the thread chart, stopping before the last machine step.



___ Step 21

- The last color in each tile is called "Seam". This
 line is the guide when trimming and stitching the
 tiles together and needs to be highly visible on
 the back side of the tile. Stitch the top color in a
 thread that blends with the fabric.
- For the bobbin, use a color that contrasts sharply with the back of the tile.
- Note: Since the bobbin color doesn't have to be the same on each tile, this is a great time to use up partially wound bobbins.






Step 22

- After embroidery is complete, press each tile face down on an OESD Perfect Embroidery Press Cloth.
- Write the number of the tile on the back so it is easily identified during construction! Use a pen or pencil that will not bleed through to the front side.
- Tip: Draw an arrow in the seam allowance pointing to the top of the tile to assist with construction.



Step 23

- At the cutting mat, place the tile right side down.
- Identify the "seam" stitch line. Trim 1/2" out from the seam stitch line, on all four sides, to create the seam allowance.
- Note: Accuracy here will significantly facilitate the construction of the scene.








Step 24

Arrange the tiles in the layout for the scene.



- Stitch two adjacent tiles, right sides together; matching the left and right sides together. Align the matching edges and stitch just inside of the seam line.
- If the seams or major points of matching do not match up, try stitching that part first. Check for accuracy.
- Repeat until all the tiles have been paired.








Step 26

- Press each seam open.
- While warm, open the seam allowance with the large ball of the OESD Expert Point and Press Tool.
- Press again and allow to cool.
- Once cool, remove the excess stabilizer in the seam allowance.
- Do not remove excess stabilizer from inside the seam line.
- Note: If the seams do not come apart easily, press both seam allowances to one side using steam and a cotton or linen setting.




- Lay out the pressed tiles.
- Stitch the third tile in the row to the other two.
- Stitch just inside the seam line, connecting the tiles.
- Press seams open.
- Repeat for remaining rows of tiles.





Step 28

- · Sew the first row of tiles to the second row.
- Align the seams.
- Stitch just inside the seam line.
- Press and remove stabilizer from the seam allowances. Then continue to stitch the rows together and press until the scene is complete.





- Cut batting and backing at least 4" larger than the tiling scene.
- Layer the backing (right side down), batting, and center the tiling scene (right side up).
- Spray baste all 3 layers with 505 Temporary Spray Adhesive.





Step 30

- Thread the sewing machine with a thread color that blends with the scene or invisible thread.
- Stitch in the ditch where the tiles connect to attach the batting and backing to the top. For best results, use a walking foot or a dual feed foot.
- Trim 1/4" from the seam line of the tiling scene through all three layers to square up the finished scene. Zigzag over the raw edges to join the edges together to make the binding process easier.




Step 31

Bind as desired.




ATTENTION

When printing this document, any page scaling or page fitting options in your print dialog box must be turned OFF or set to NONE so that your files will print out at their actual size. Images not printed at actual size will not function as intended.




TO SAVE PAPER

Only print the desired image by navigating to the image's page, go to File > Print and select "Current page" in the print dialog box. Repeat for each desired image.




APPLIQUE PATTERNS OSSI






APPLIQUE PATTERNS OSE






APPLIQUE PATTERNS OSSI





APPLIQUE PATTERNS OS






APPLIQUE PATTERNS O SD PREMIER COLLECTION




80401-06

Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.




APPLIQUE PATTERNS O SD PREMIER




APPLIQUE PATTERNS OSI






APPLIQUE PATTERNS OSSI







measures 1" x 1". Use the box as an accuracy guide when printing templates. 80401-04 Mirrored 80401-03 Mirrored 80401-02 Mirrored 80401-03 Mirrored 80401-02 Mirrored

Print at 100%. No scaling. This box

