

# Product Usage Instructions

## PolyMesh CutAway Stabilizer

---

- Cut one or more pieces of PolyMesh CutAway stabilizer about 2" larger than the hoop.
- Spray the PolyMesh CutAway with temporary spray adhesive. If you are using multiple layers of stabilizer, adhere all layers together with temporary spray adhesive.
- Center the sprayed side of the PolyMesh over the design area on the back of the fabric to be embroidered.
- Gently smooth into place.
- Hoop the item making sure that the PolyMesh completely fills the hooped area.
- HINT: A topper, StitchH2O or Heat2Go, should be used on top of all knits, fleece, terry cloth, and other fabrics with a texture or pile.
- Embroider the item.

### REMOVAL INSTRUCTIONS:

- Remove the embroidered item from the hoop.
- Lay the embroidered item on a hard, flat surface with the stabilizer side down.
- Lift and fold the embroidered fabric away from the stabilizer and carefully trim the excess stabilizer away.
- For multiple layers of stabilizer, trim one layer at a time.



[www.OESD.com](http://www.OESD.com)