

Product Usage Instructions

Fuse & Seal

- Trace the image of the badge, patch, applique or embroidery design, right side down, on to the paper side of Fuse and Seal.
- Cut the Fuse and Seal shape to size.
- Lay the piece of Fuse and Seal with the film side against the back of the badge, patch, applique or embroidery design. The white liner paper should be up.
- Heat household iron to wool setting.
- Press the iron on the white paper 8-12 seconds. (Test before use)
- Allow to cool.
- Remove white liner paper. Your design now has Fuse and Seal's heat sealable film attached.
- Design can now be ironed on to garment or other project.
- For best adhesion, also press from the back side of the fabric to apply more heat to the adhesive.
- When possible, apply iron to the back of the fabric to ensure a complete fuse.
TIP: When ironing design, wool setting and dwell time of 8-12 seconds is recommended. However, different fabrics may require higher temperature settings and dwell time. Pre-test settings before doing project.