

Product Usage Instructions

AquaMesh WashAway Stabilizer

LIGHTWEIGHT FABRIC INSTRUCTIONS:

- Cut a piece of AquaMesh approximately 2" larger than your hoop.
- Lightly spray AquaMesh with temporary spray adhesive.
- Place AquaMesh against the wrong side of the fabric, centering over the design area.
- Some designs may require 2 pieces.
- Embroider the design.

FREESTANDING DESIGN INSTRUCTIONS:

NOTE: Stand-alone lace designs have been specifically created to be stitched on water-soluble stabilizer alone. Not all lace designs are created to be stand-alone designs. If you are not sure about the design you plan to use, check with the design's creator. OESD freestanding designs have a reference in the design name including FSL (Freestanding Lace) and FSA (Freestanding Applique).

- Cut two hoop-sized pieces of AquaMesh.
- Hoop all layers as one and stitch the stand-alone design.
- Follow removal instructions to remove excess stabilizer.

REMOVAL INSTRUCTIONS:

- Remove the embroidered item from the hoop.
 - Carefully trim away the excess AquaMesh, leave about 1/4" of stabilizer around the design.
 - Rinse away any remaining stabilizer under warm running water. If a stiffer lace product is desired, rinse for a shorter time.
-



www.OESD.com