

#12593 / 6 Designs

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



12593-01 Small Snap Pouch 1 3.25 X 6.49 in. 82.55 X 164.85 mm



12593-04 Large Snap Pouch 2 3.75 X 6.85 in. 95.25 X 173.99 mm 3.361 St. ₩ L



12593-02 Large Snap Pouch 1 3.75 X 6.85 in. 95.25 X 173.99 mm 3.878 St. **36** L



12593-05 Small Snap Pouch 3 3.25 X 6.49 in. 82.55 X 164.85 mm 3.842 St. **36** L



12593-03 Small Snap Pouch 2 3.25 X 6.49 in. 82.55 X 164.85 mm 2,688 St. **3** L



12593-06 Large Snap Pouch 3 3.75 X 6.85 in. 95.25 X 173.99 mm 5,224 St. **36** L

- # Design contains a loose fill.
- Some solid areas shown are not stitched.

- L Design is larger than 5" (127 mm) in either direction.
- S Design is smaller than 1.5" (38.1 mm) in either direction.



#12593 / 6 Designs

Listings below indicate color sample, stitching order and suggested thread color number. Most numbers indicate Isacord thread. Colors beginning with 20501 refer to YLI Fine Metallics, 7 refer to Yenmet Metallic, 8 refer to YLI Variations Variegated Thread and 9 refer to Isacord Multicolor Variegated.

12593-01 Small Snap Pouch 1 0020 1. Panel Placement Stitch	12593-03 Small Snap Pouch 2 0020 1. Panel Placement Stitch	12593-05 Small Snap Pouch 3 0020 1. Panel Placement Stitch 0020 2. Panel Tackdown 0020 3. Panel Motif 0020 4. Ribbon Placement Stitch 0020 5. Ribbon Tackdown 0020 6. Back Panel & Front Panel Tackdown 0020 7. Seam Stitch 0020
12593-02 Large Snap Pouch 1 0020 1. Panel Placement Stitch	12593-04 Large Snap Pouch 2 ■ 1. Panel Placement Stitch	12593-06 Large Snap Pouch 3 0020 1. Panel Placement Stitch 0020 2. Panel Tackdown 0020 3. Panel Motif 0020 4. Ribbon Placement Stitch 0020 5. Ribbon Tackdown 0020 6. Back Panel & Front Panel Tackdown 0020 7. Seam Stitch 0020



Instructions

Create a small handy snap pouch in the hoop of your embroidery machine for carrying lipstick, lip balm, USB stick, etc. Add a key ring and lobster clasp for ease of attaching to your keys. In the Hoop Snap Pouches #12593 feature 6 different styles and sizes to choose from. Make several as gifts. They are simple and easy "in the hoop".

Supplies

- OESD Embroidery collection In the Hoop Snap Pouches #12593
- Medium tear away stabilizer
- 1/8 yd. fabric (large or small pouch)
- (1") piece ribbon or trim (ring tab)
- Metal key ring
- Snap fasteners
- Isacord embroidery threads
- Temporary spray adhesive
- Optional: Lobster clasp

Cut

Large Pouch

- (1) 3 ½" x 15" piece fabric (fold in half to measure 3 ½" x 7 ½") (Panel)
- (1) 3 ½" x 7 ½" piece fabric (Back Panel)
- (1) 3 ½" x 7" piece fabric (fold in half to measure 3 ½" x 3 ½") (Top Panel)
- (1) 3 ½" x 10" piece fabric (fold in half to measure 3 ½" x 5") (Bottom Panel)

Small Pouch

- (1) 2 ½" x 15" piece fabric (fold in half to measure 2 ½" x 7 ½") (Panel)
- (1) 2 ½" x 7 ½" piece fabric (Back Panel)
- (1) 2 ½" x 6" piece fabric (fold in half to measure 2 ½" x 3") (Top Panel)
- (1) 2 ½" x 9" piece fabric (fold in half to measure 2 ½" x 4 ½") (Bottom Panel)

Instructions

- Hoop tear away stabilizer.
- Stitch the first stitch of the embroidery design which is the Panel Placement Stitch. **PHOTO 1**
- Using Panel fabric piece, fold in half, wrong sides together. Press. Center and place the Panel fabric over the Panel Placement Stitch. Stitch the second stitch of the embroidery design called Panel Tackdown. PHOTO 2
- Stitch the next color called Panel Motif. PHOTO 3
- Stitch the next color called Ribbon Placement
 Stitch (it is stitched in black for visual purposes).
 PHOTO 4
- Fold ribbon in half with raw edges even. Center and place raw edges on the top of the Ribbon Placement Stitch. PHOTO 5
- Stitch the next color called Ribbon Tackdown. **PHOTO** 6
- Take the hoop off the embroidery machine and spray the back of the hoop with temporary spray





Instructions

adhesive. Center and place Back Panel fabric right side up over the back of hoop and lining up with the panel fabric piece. **PHOTO** 7

- Using Top and Bottom Panel fabric pieces, fold in half, wrong sides together. Press.
- Optional: Extend the Panel Guides with pencil. (seen in red in photo) Center and place Bottom Panel fabric with folded edge lining up with the Top Placement Guide. PHOTO 8
- Center and place Top Panel fabric with folded edge lining up with the Bottom Placement Guide, overlapping the Bottom Panel fabric. PHOTO 9
- Stitch the next stitch called Back Panel and Front Panel Tackdown. **PHOTO 10**
- Stitch the last stitch called Seam Stitch. This will stitch the sections together. **PHOTO 11**
- Remove the pouch from the hoop and trim excess stabilizer and fabric 1/4" from seam stitch. **PHOTO 12**
- Turn right side out. Press. PHOTO 13
- Following manufacturer's directions, add snap to the top flap and bottom panel. Note: Place the item(s) in the pouch and mark the placement for the snaps. This is so there is plenty of room for the items with the pouch snapped.
- Add the metal key ring to the ribbon loop. Optional: Add the lobster clasp to the metal key ring for ease of putting on keychain or belt loop. PHOTO 14
- Insert lipstick, lip balm, USB stick or multiple things in your handy In the Hoop Snap Pouch. Enjoy!



