





Isacord Thread Colors

0015 White 0020 Black 0111 Whale 0142 Sterling 0311 Canary 0442 Tarnished Gold 0622 Star Gold 0670 Cream 0800 Golden Rod 0853 Pecan 0874 Gravel 0904 Spanish Gold 0922 Ashley Gold 0933 Redwood 0934 Fawn	1123 Caramel Cream 1220 Apricot 1352 Salmon 1840 Corsage 1950 Tropical Pink 2101 Country Red 2171 Blush 2300 Bright Ruby 2504 Plum 2508 Hot Pink 2520 Garden Rose 2521 Fuschia 2532 Pretty in Pink 2764 Violet 2912 Sugar Plum	3711 Dolphin Blue 3962 River Mist 4133 Deep Ocean 4220 Island Green 4240 Spearmint 4332 Rough Sea 4515 Spruce 4610 Deep Aqua 4620 Jade 4952 Mystic Ocean 5050 Luster 5115 Baccarat Green 5510 Emerald 5730 Apple Green
0934 Fawn 1055 Bark	2912 Sugar Plum 3040 Lavender	5912 Erin Green 6051 Jalapeno

^{*}Project instructions included after design list







12615-01 Blank Medallion Greeting Card

Size Inches:	Size mm:	Stitch Count:
4.62 X 6.25 in.	117.35 X 158.75 mn	n 2,643 St.
1. Card Place	ement Stitch	5912
2. Top Right/N	Middle Left Placement S	titches 5912
3. Top Right/N	Middle Left Tackdowns	5912
4. Middle Rig	ht/Bottom Left Placeme	nt Stitches 4220
5. Middle Rig	ht/Bottom Tackdowns	4220
☐ 6. Top Left/Bo	ottom Right Placement S	Stitches 0015
☐ 7. Top Left/Bo	ottom Right Tackdowns.	0015
8. Circle Plac	ement Stitch	5912
9. Circle Tack	down	5912
■ 10. Circle Inne	r Linework	0020



12615-02 Butterfly Rainbow Greeting Card

Size Inches:	Size mm:	Stitch Count:
4.62 X 6.25 in.	117.35 X 158.75 mm	4,011 St.
1. Card Place	ement Stitch	2520
2. Pink Stripe	Placement Stitch	2520
3. Pink Stripe	Tackdown	2520
	pe Placement Stitch	
5. Yellow Stri	pe Tackdown	0800
6. Aqua Strip	e Placement Stitch	5115
7. Aqua Strip	e Tackdown	5115
8. Blue Stripe	es Placement Stitch	3711
9. Blue Stripe	es Tackdown	3711
-	lacement Stitch	
= 11. Butterfly Ta	ackdown and Detail	2300
12. Clouds		4240







12615-03 Christmas Tree Greeting Card

Size Inches:	Size mm:	Stitch Count:
4.62 X 6.25 in.	117.35 X 158.75 mm	3,578 St.
1. Card Place	ment Stitch	5730
2. Middle Pan	el Placement Stitch	5730
3. Middle Par	el Tackdown	5730
4. Top and Bo	ottom Panel Placement St	itches 5730
5. Top and Bo	ottom Panel Tackdowns	5730
6. Swirls		4332
7. Tree Place	ment Stitch	5510
8. Tree Tackd	own	5510
9. Star Placer	ment Stitch	1840
10. Star Tackdo	own	1840
11. Star and Tr	ee Red Detail	2101



12615-04 Present Greeting Card

Size Inches:	Size mm:	Stitch Count:
4.62 X 6.25 in.	117.35 X 158.75 mm	3,412 St.
1. Card Place	ement Stitch	4610
2. Ribbon Pla	acement Stitch	4610
3. Ribbon Ta	ckdown	4610
4. Box Place	ment Stitch	0922
5. Box Tackd	own	0922
6. Swirls		0934
7. Bow Place	ement Stitch	4515
8. Bow Tack	down	4515
9. Light Blue	Bow Detail	5050







12615-05 Flower Greeting Card

	Size mm: 117.35 X 158.75 mm	
4.02 A 0.23 III.	117.33 A 130.73 IIIII	3,007 31.
1. Card Place	ement Stitch	0800
2. Bottom Pa	nel Placement Stitch	0800
3. Bottom Pa	nel Tackdown	0800
4. Left Panel	Placement Stitch	0800
5. Left Panel	Tackdown	0800
6. Right Pane	el Placement Stitch	0800
7. Right Pane	el Tackdown	0800
	ers	
9. Flower and	Leaves Placement Stitch	es 2171
10. Flower and	Leaves Tackdown	2171
11. Pink Flowe	er Detail	2521



12615-06 Moustache Greeting Card

Size Inches:	Size mm:	Stitch Count:
4.62 X 6.25 in. 1	17.35 X 158.75 mm	4,586 St.
1. Card Placen	nent Stitch	1123
2. Background	Placement Stitches	1123
3. Background	Tackdown	1123
4. Hat Placeme	ent Stitch	0874
5. Hat Tackdow	/n	0874
6. Moustache F	Placement Stitch	0111
7. Moustache	Tackdown	0111
8. Bow Tie Place	cement Stitch	1055
9. Bow Tie Tac	kdown	1055







12615-07 Rose Greeting Card

Size Inches:	Size mm:	Stitch Count:
4.62 X 6.25 in.	117.35 X 158.75 mm	3,604 St.
1. Card Place	ment Stitch	5115
2. Middle Pan	el Placement Stitch	5115
3. Middle Pan	el Tackdown	5115
4. Top and Bo	ttom Panel Placement St	titches5115
5. Top and Bo	ttom Panel Tackdowns	5115
6. Purple Vine)	2764
7. Flower and	Leaves Placement Stitch	nes 2508
8. Flower and	Leaves Tackdown	2508
9. Purple Flov	ver and Leaves Detail	2504



12615-08 Cross Greeting Card

Size Inches:	Size mm:	Stitch Count:
4.62 X 6.25 in.	117.35 X 158.75 mm	n 3,172 St.
1. Card Place	ement Stitch	4952
2. Middle Par	nel Placement Stitch	4952
3. Middle Par	nel Tackdown	4952
4. Top and Bo	ottom Panel Placement	Stitches 0622
5. Top and Bo	ottom Panel Tackdowns	0622
6. Cross Place	cement Stitch	0670
7. Cross Tack	kdown	0670
8. Brown Cro	ss Linework	0853
9. Swirls		5115







12615-09 Balloons Greeting Card

Size Inches:	Size mm:	Stitch Count:
4.62 X 6.25 in.	117.35 X 158.75 mm	4,498 St.
1. Card Place	ement Stitch	1352
2. Top Panel	Placement Stitch	1352
3. Top Panel	Tackdown	1352
4. Middle Par	nel Placement Stitch	1352
5. Middle Par	nel Tackdown	1352
6. Bottom Pa	nel Placement Stitch	1352
7. Bottom Pa	nel Tackdown	1352
8. Middle Bal	loon Placement Stitch	0311
9. Middle Bal	loon Tackdown and Detail	0311
■ 10. Top Balloo	n Placement Stitch	1950
11. Top Balloo	n Tackdown and Detail	1950
12. Bottom Ba	lloon Placement Stitch	5912
= 13. Bottom Ba	lloon Tackdown and Detai	I 5912
□ 14. White Deta	ail	0015



12615-10 Hearts Greeting Card

Size Inches:		
4.62 X 6.25 in.	117.35 X 158.75 mm	3,955 St.
1. Card Place	ment Stitch	0142
2. Right Pane	I Placement Stitch	0142
3. Right Pane	I Tackdown	0142
4. Middle Pan	el Placement Stitch	0142
5. Middle Pan	el Tackdown	0142
6. Left Panel	Placement Stitch	0142
7. Left Panel	Tackdown	0142
□ 8. Heart Place	ement Stitches	0015
9. Heart Tack	downs	0015
10. Pink Detail		1840
1 1. Swirls		2101







12615-11 Baby Greeting Card

Size Inches:	Size mm:	Stitch Count:
4.62 X 6.25 in.	117.35 X 158.75 mm	2,596 St.
1. Card Place	ement Stitch	3040
2. Top Panel	Placement Stitch	3040
3. Top Panel	Tackdown	3040
4. Bottom Par	nel Placement Stitch	3040
5. Bottom Par	nel Tackdown	3040
6. Left Panel	Placement Stitch	3040
7. Left Panel	Tackdown	3040
8. Green Line	work	6051
9. Onesie Pla	cement Stitch	2520
10. Onesie Tad	kdown	2520



12615-12 Ornaments Greeting Card

Size Inches:	Size mm:	Stitch Count:
4.62 X 6.25 in.	117.35 X 158.75 mm	3,064 St.
1. Card Place	ment Stitch	0142
2. Top Panel Placement Stitch		0142
	Tackdown	
4. Middle Par	nel Placement Stitch	0142
5. Middle Par	nel Tackdown	0142
6. Bottom Pai	nel Placement Stitch	0142
7. Bottom Par	nel Tackdown	0142
8. Top Ornam	ent Placement Stitch	1220
9. Top Ornam	ent Tackdown	1220
10. Bottom Orr	nament Placement Stitch.	5730
11. Bottom Orr	nament Tackdown	5730
12. Swirls		4952
☐ 13. White Deta	il	0015







12615-13 Bird Greeting Card

	Size mm: 117.35 X 158.75 mm	
 Card Place Top Panel Top Panel Middle Par Middle Par Bottom Pa Bottom Pa Bird Place Bird Tackd Flower Pla 	ement Stitch	
	/er	_



12615-14 Abstract Greeting Card

Size Inches:	Size mm:	Stitch Count:
4.62 X 6.25 in. 1	17.35 X 158.75 mm	2,179 St.
☐ 1. Card Placem	ent Stitch	0015
2. White Panels	Placement Stitch	0015
☐ 3. White Panels	Tackdowns	0015
4. Blue Panels	Placement Stitch	4133
5. Blue Panel T	ackdowns	4133







12615-15 Easter Egg Greeting Card

Size Inches:	Size mm:	Stitch Count:
4.62 X 6.25 in.	117.35 X 158.75 mm	2,783 St.
1. Card Place	ment Stitch	2532
2. Bottom Panel Placement Stitch		2532
3. Bottom Par	nel Tackdown	2532
4. Middle Pan	el Placement Stitch	2532
5. Middle Pan	el Tackdown	2532
6. Top Panel I	Placement Stitch	2532
	Tackdown	
8. Egg Top Pla	acement Stitch	1220
	ckdown	
10. Egg Middle	Placement Stitch	5730
11. Egg Middle	Tackdown	5730
■ 12. Egg Bottom	n Placement Stitch	2912
	n Tackdown	

COLLECTION SUPPLIES



Stabilizers

- OESD Medium Weight TearAway
- OESD Fuse and Seal
- OESD Applique Fuse and Fix

Fabrics/Textiles

- Start Here Embroidery Blanks by OESD Greeting Card size A6 (4.62" x 6.25") folded.
- Applique fabrics

Notions & Tools

- Organ 75/11 Embroidery Sharp Needle (Titanium optional)
- Detail Scissors
- OESD Bobbin Thread White

Isacord Thread Colors

· Per thread chart



STEP 1

- Print the Mirrored Applique Template for design 12615-09 onto the paper side of a piece of Applique Fuse and Fix.
- Roughly cut out the templates.
- Tip: Print templates at 100%.



STEP 2

- Fuse the trimmed templates onto the back of the applique fabrics with a medium iron.
- Trim each applique piece precisely on the outer edge of the black line.
- Cut one card in half on the fold line.



- Hoop a piece of Medium Weight TearAway.
- Load design 12615-09 into the machine.
- Thread the machine per the thread chart.
- Stitch Machine Step 1, Card Placement Stitch.






STEP 4

- Place the cut piece of card stock within the placement stitch, lining up all edges.
- Tape in place to secure.
- Tip: Slow embroidery machine down when stitching on paper and turn off jump stitch cutter for a cleaner design back.



STEP 5

- Stitch Machine Step 2, Top Right & Middle Left Placement Stitches.
- Remove the hoop from the machine, but not the project from the hoop.
- Place on a flat surface.



- Score the paper on the back of the Top Right and Middle Left applique pieces and remove the paper.
- Place within the placement stitch with the sticky side to the card. If necessary, the applique can be repositioned.
- Return the hoop to the machine.





STEP 7

- Stitch Machine Step 3, Top Right & Middle Left Tackdowns.
- Change thread to Blue.
- Stitch Machine Step 4, Middle Left & Bottom Right Placement Stitches.



STEP 8

- Repeat steps 5-7 for the remaining appliques changing thread colors as required. (Machine Steps 5-9)
- Change the thread to Black.
- Stitch Machine Step 10, Circle Inner Linework.



- Remove the cardstock and stabilizer from the hoop. Place the card face down and fold the stabilizer towards the card.
- Carefully cut the stabilizer away, close to the stitching.
- Note: Even though the stabilizer is a tear away, it is better to cut the stabilizer away from the card to prevent bending or creasing the cardstock.





STEP 10

- With a medium warm iron, press the Fuse and Seal to the back of the embroidered cardstock.
- Once cool, remove the paper backing.



- Place the embroidered half of the card over the front of the second card and fuse with a medium warm iron.
- The back of the embroidery is now hidden.




PRINTING INSTRUCTIONS




ATTENTION

When printing this document, any page scaling or page fitting options in your print dialog box must be turned OFF or set to NONE so that your files will print out at their actual size. Images not printed at actual size will not function as intended.



TO SAVE PAPER

Only print the desired image by navigating to the image's page, go to File > Print and select "Current page" in the print dialog box. Repeat for each desired image.





Print at 100%. No scaling. This box measures 1"x 1". Use the box as an accuracy guide when printing templates.

12615-01 Bottom Left Square 12615-01 Middle Left Square


12615-01 Top Left Square


12615-01 Bottom Right Square

12615-01 Middle Right Square 12615-01 Top Right Square


12615-01 Circle

























Print at 100%. No scaling. This box measures 1"x 1". Use the box as an accuracy guide when printing templates.


12615-05 Left Panel 12615-05 Bottom Panel

> 12615-05 Right Panel






Print at 100%. No scaling. This box measures 1"x 1". Use the box as an accuracy guide when printing templates.



12615-06 Right Background







Print at 100%. No scaling. This box measures 1"x 1". Use the box as an accuracy guide when printing templates.


12615-07 Bottom Panel 12615-07 Middle Panel

12615-07 Top Panel




















Print at 100%. No scaling. This box measures 1"x 1". Use the box as an accuracy guide when printing templates.

12615-10 Left Panel Middle Panel Right Panel






Print at 100%. No scaling. This box measures 1"x 1". Use the box as an accuracy guide when printing templates.


12615-11 Left Panel


> 12615-11 Bottom Panel

12615-11 Top Panel



































12615-01 Top Left Square 12615-01 Middle Left Square 12615-01 Bottom Left Square Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.

12615-01 Top Right Square 12615-01 Middle Right Square 12615-01 Bottom Right Square




























Print at 100%. No scaling. This box measures 1"x 1". Use the box as an accuracy guide when printing templates.

12615-05 Left Panel

> 12615-05 Right Panel

12615-05 Bottom Panel






Print at 100%. No scaling. This box measures 1"x 1". Use the box as an accuracy guide when printing templates.

12615-06 Left Background

> 12615-06 Middle Background

12615-06 Right Background




12615-07 Top Panel




Print at 100%. No scaling. This box measures 1"x 1". Use the box as an accuracy guide when printing templates.


12615-07 Middle Panel

12615-07 Bottom Panel




















Print at 100%. No scaling. This box measures 1"x 1". Use the box as an accuracy guide when printing templates.

12615-10 Left Panel

> 12615-10 Middle Panel

12615-10 Right Panel






eft Panel


Print at 100%. No scaling. This box measures 1"x 1". Use the box as an accuracy guide when printing templates.


12615-11 Top Panel

12615-11 Bottom Panel













Print at 100%. No scaling. This box measures 1"x 1".
Use the box as an accuracy guide when printing templates.

12615-13 Top Panel Middle Panel 12615-13 Bottom Panel










Print at 100%. No scaling. This box measures 1"x 1". Use the box as an accuracy guide when printing templates.



12615-15 Bottom Panel

