







12770-01 Word Art Sewing Machine


Size Inches: 5.42 X 5.51 in.	Size mm: 137.67 X 139.95 mm	
2. Baby Blue 3. Coral Word	Words Words Is etail	3652 1532

12770-02 Word Art Flower

Size Inches: 3.41 X 8.71 in.	Size mm: 86.61 X 221.23 mm	
 2. Erin Green 3. Pecan Wor 4. Goldenrod 5. Daisy Word 	s and Stem Words d Words Is	
6. Yellow Wor	ds	0310







12770-03 Word Art Apple

Size Inches: 5.41 X 6.29 in.	Size mm: 137.41 X 159.77 mm	
 2. Lime Word 3. Strawberrie 4. Strawberry 5. Lipstick Word 	rd es N' Cream Words Words ords y Words	

12770-04 Word Art Purse

Size Inches: 5.33 X 5.03 in.	Size mm: 135.38 X 127.76 mm	
2. Amethyst V3. Frosted Or4. Lavender V	Words Nords chid Words Nords sion Words	







12770-05 Word Art Crown

Size Inches: 3.70 X 5.88 in.	Size mm: 93.98 X 140.97 mm	
2. Daisy Word3. Rose Word	Vords and Dots ls s and Dots Words	0605 2530



12770-06 Word Art Dog

Size Inches:		
5.43 X 6.72 in.	137.92 X 170.69 mm	19,916 St.
1. Silver Sage	e Words	5220
2. River Mist	Words	3962
3. Tropical Bl	ue Words	3901
4. Marine Aqu	ia Words	4423







12770-07 Word Art Cat

Size Inches: 3.23 X 6.16 in.	Size mm: 82.04 X 156.46 mm	
2. Raspberry3. Iris Blue We	Vords Words ords ords	

12770-08 Word Art Heart

Size Inches:	Size mm:	Stitch Count:
4.56 X 4.41 in.	115.82 X 112.01 mm	12,171 St.
2. Corsage W3. Strawberrie4. Raspberry	I /ord es N' Cream Words Words 	







12770-09 Word Art House

Size Inches: 4.10 X 4.60 in.	Size mm: 104.14 X 116.84 mm	
2. Daisy Word3. Harvest Wo4. Lipstick Wo	inge Words ds ords ords y Words	

12770-10 Word Art Cross

Size Inches: 4.46 X 7.85 in.	Size mm: 113.28 X 199.39 mm	
 Aquamarin 2. Basic Seaf 3. Tamarack 	e Words oam Words Words Ja Words	







12770-11 Word Art Cup

Size Inches: 4.68 X 4.50 in.	Size mm: 118.87 X 114.30 mm	
2. Fire Blue W3. Blue Ribbo	Words /ords n Words st Smoke	3333 3611

12770-12 Word Art Tree

Size Inches: 5.56 X 5.94 in.	Size mm: 141.22 X 150.88 mm	
2. Fawn Word	ds ls	
4. Mint Words	Nords 3	
6. Yellowgree	sn Words n Words n Words	6043

MATERIALS



Stabilizer

- Fusible Polymesh CutAway
- StitcH2O WashAway Topping
- Gentle Touch Backing (optional)

Fabric/Notions

- T-shirt
- Expert Embroidery Tape TearAway
- Removeable marking pen
- Ruler
- Software capable of printing templates
 - NOTE Bernina Artlink is a free download with the capabilities required for this project. See www.berninausa.com for download information.

Isacord Thread Colors

0310	Yellow	2320	Raspberry	3901	Tropical Blue
0605	Daisy	2530	Rose	3962	River Mist
0800	Golden Rod	2650	Impatiens	4174	Charcoal
0853	Pecan	2704	Purple Passion	4423	Marine Aqua
0934	Fawn	2732	Frosted Orchid	4740	Aquamarine
1200	Sunset Orange	2905	Iris Blue	5220	Silver Sage
1332	Harvest	3030	Amethyst	5440	Mint
1532	Coral	3040	Lavender	5450	Basic Seafoam
1753	Strawberries N' Cream	3333	Fire Blue	5633	Lime
1805	Strawberry	3611	Blue Ribbon	5912	Erin Green
1840	Corsage	3630	Sweet Boy	5934	Moss Green
1903	Lipstick	3652	Baby Blue	6011	Tamarack
1912	Winterberry	3750	Winter Frost	6043	Yellowgreen

INSTRUCTIONS

STEP1

In software, print a template of the design. The design must be printed at 100%, or 1:1 size since it will be used for placement on the t-shirt. Trim around the design. Slit the crosshair open and fold back opposite sides for marking ease.

STEP 2

- Prewash and dry the t-shirt to preshrink before embroidering. Turn shirt inside out. Press without stretching the fabric.
- Cut 2 pieces of Fusible Polymesh CutAway, about 2 inches larger than the hoop. Fuse one layer following package directions to the inside of the shirt front. Fuse the second piece over the first. Turn the shirt right side out.
- Note: CutAway stabilizer is required when stitching on knits and any garment that will be subject to frequent washings. Polymesh CutAway is light weight and provides excellent stability without changing the drape of the fabric.

STEP 3

Fold the t-shirt in half lengthwise matching the underarm and shoulder seams. Finger press to create a slight crease down the front of the shirt. Position the template along the crease matching the vertical crosshair of the template and the tope of the design about 1" from the bottom of the collar.









INSTRUCTIONS

10

STEP 4

• Using a temporary fabric marker, mark both the vertical and horizontal centers directly onto the t-shirt. Set the template aside. Extend the lines of the crosshair to the full size of the hoop for ease in hooping.

STEP 5

Use the hoop template to assist in hooping the shirt. Align the template with the vertical crosshair line. The horizontal lines should be inline with the horizontal lines on the hoop template. In this instance, the design is moved up in the hoop because of the proximity to the collar.

STEP 6


 Once hooped, pull the back of the t-shirt to the top of the hoop. Tape the excess out of the way of the design with Expert Embroidery Tape TearAway. It is acceptable, as well as helpful, to pull the tape to the back of the hoop to secure. This will help insure that none of the t-shirt next to the design area gets caught in the stitching.

> It is a violation of Copyright law to make and distribute copies of electronic designs or artwork. Electronic designs are licensed to the original purchaser for use at one location. ©2018 OESD, LLC. All rights reserved.









that the needle is in the center of the crosshair.

INSTRUCTIONS


STEP 8

STEP 7

- Before pressing Go, cover the design area with a piece of StitcH2O topping. It will prevent the stitches from sinking into the soft knit of the shirt and dramatically improves the look of satin stitches on any fabric.
- Press Go. Change threads as necessary to complete the design. • Trim any untrimmed jump stitches at the color changes.

It is a violation of Copyright law to make and distribute copies of electronic designs or artwork. Electronic designs are licensed to the original purchaser for use at one location. ©2018 OESD, LLC. All rights reserved.

11






STEP 9

- Remove the t-shirt from the hoop. Tear away the excess topping and remove the rest by washing or spritzing with water and blotting with a dry towel.
- Trim the Polymesh Stabilizer to about 1/4" around the design. • Be careful to not trim the shirt accidentally.





INSTRUCTIONS



STEP 10

 Optional: Cut a piece of Gentle Touch backing large enough to completely cover the design. Fuse the backing in place per the printed instructions. This backing will prevent the bobbin stitches from irritating sensitive skin. And, since it is a permanent fuse, it will stay in place through washing and wearing!



