

LIVE LOVE BAKE







Isacord Thread Colors

0101 Eggshell	1755 Hyacinth	3241 Amethyst Frost
0651 Cornsilk	1903 Lipstick	3840 Oxford
0781 Candlewick	1921 Blossom	4752 Vintage Blue
1010 Toast	2152 Heather Pink	
1335 Dark Rust	2300 Bright Ruby	

^{*} Project instructions included after design list.


Note: One spool of 1000 meter thread is adequate for the project unless otherwise noted.

TABLE OF CONTENTS

Designs	3
Collection Supplies	7
Embroidery	8
Printing Instructions	13
Applique Patterns	14
Mirrored Patterns	18







12932-01 Life Is Short Make It Sweet

Size Inches: 7.02 X 5.27 in.	Size mm: 178.3 X 133.9 mm	
1. Plate		4752
2. White Cake	Detail	0101
3. Light Pink D	Detail	1755
4. Pink Cake [Detail	1921
5. White Seed	S	0101
6. Orange Det	ail	1010
7. Pink Letteri	ng	1921
8. Blue Letteri	ng	4752



12932-02 Just Roll With It

Size Inches:	Size mm:	Stitch Count:
6.77 X 5.88 in.	172.0 X 149.3 mm	9731 St.
1. Orange Det	ail	1010
2. Tan Pin Hig	hlights	0781
3. Blue Detail.	-	4752
4. Pink Detail.		1921
5. Tan Letterin	g and Swirls	0781








12932-03 Baking Supplies

Size Inches:	Size	mm:	Stitch Count:
7.04 X 4.44 in.	178.8 X	112.7 mm	12198 St.
1. White Label	S		0101
2. Blue Whisk	and Bottles	S	4752
3. Light Pink C	ap and Lal	oel	1755
4. Pink Lettering	-		
5. Red Letterin	ig and Cap		1903
6. Pink Fabric	Placement	Stitch	2300
7. Blanket Stite	ch Tackdow	/n	2300
8. Orange Fab	ric Placem	ent Stitch	1335
9. Blanket Stite	ch Tackdow	/n	1335
10. Blue Fabric	Placement	Stitch	4752
11. Blanket Stite	ch Tackdow	/n	4752
12. Purple Deta	il		3241
13. Orange Det			
14. Light Pink D			
15. White Highl	ghts		0101



12932-04 Live Love Bake

Size Inches:	Size mm:	Stitch Count:
7.10 X 4.91 in.	180.3 X 124.7 mm	13366 St.
1. Pink Letteri	ng	1921
2. Orange De	tail	1010
_		
4. Pink Handle	es	1921
5. White Deta	il	0101







12932-05 Cake Mixing

Size Inches: 6.83 X 6.09 in.	Size mm: 173.6 X 154.6 mm	
1. Blue Whisk	S	4752
2. Purple Deta	ail	3241
3. Blue Fabric	Placement Stitch	4752
4. Blanket Stit	ch Tackdown	4752
5. Orange Fal	oric Placement Stitch	1010
6. Blanket Stit	ch Tackdown	1010
7. Tan Highlig	hts	0781
8. Tan Batter.		0781
9. White Detail	il	0101




12932-06 Baking Utensils

Size Inches:	Size mm:	Stitch Count:
7.04 X 5.07 in.	178.9 X 128.7 mm	16000 St.
1. Blue Detail		4752
2. Purple Deta	ail	3241
3. Pink Detail		1921
4. Light Pink [Detail	1755
5. White Deta	il	0101
6. Tan Detail .		0781







12932-07 Baked with Love

	Size mm: 178.0 X 126.7 mm	
1. Orange Fal	oric Placement Stitch	1010
2. Blanket Stit	ch Tackdown	1010
3. White Lette	ring	0101
4. Pink Letteri	ng	1921
5. Pink Swirls	-	1921
6. White Hear	t and Bread	0101



12932-08 Donut Worry Be Happy

Size Inches:	Size mm:	Stitch Count:
5.42 X 4.84 in.	137.8 X 122.8 mm	15417 St.
1. Tan Fabric	Placement Stitch	0651
2. Blanket Stit	ch Tackdown	0651
3. Medium Pir	nk Icing	2152
4. Medium Pir	nk Lettering	2152
5. Blue Letter	ing	4752
6. Blue Swirls		4752
7. Light Blue	Sprinkles	3840
8. White Deta	il	0101

COLLECTION SUPPLIES



Stabilizers

- OESD Medium Weight TearAway Stabilizer Black
- OESD Applique Fuse and Fix

Fabrics/Textiles

- · Assorted colors of cotton fabric squares
 - Refer to the applique templates for sizes
- Start Here by OESD Tea Towel Blue

Notions & Tools

- OESD Perfect Embroidery Press Cloth
- OESD Grippy Grid

Isacord Thread Colors

• Per thread chart

EMBROIDERY




Notes

The applique instructions included in the design pack are general instructions for the collection. For demonstration purposes, a sample design that best represents the entire collection is shown. Fabric and thread requirements will vary by design, but the general technique will be the same.


STEP 1

- Print the mirrored version of the required templates (100% or 1:1 ratio) onto the paper side of Applique Fuse and Fix.
- Roughly cut out each template about a 1/4" outside of the line.





- Fuse the trimmed templates to the back of the appropriate applique fabric with the paper side of the printed template up.
- Hold the iron on the template for 10-15 seconds for a secure fuse.




ASSEMBLY



STEP 3

- Trim the prepared appliques precisely on the outer edge of the black outline.
- Set aside.





STEP 4

 Hoop the desired stabilizer and fabric for the project, in the example we used Medium Weight TearAway Black and an OESD tea towel in blue.



- · Load the selected design into the machine.
- Design in the example is 12932-05.
- Thread the machine per the thread chart.
- Stitch Machine Step 1, Blue Whisks.
- Stitch Machine Step 2, Purple Detail.







STEP 6

• Stitch Machine Step 3, Blue Fabric Placement Stitch.



STEP 7

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Remove the paper from the back of the prepared applique to expose the adhesive surface.
- Position the applique, fabric side up, within the placement stitch, matching the cut edges with the stitching line.
- Finger press to secure.
- Note: Applique Fuse and Fix is repositionable.



- · Return the hoop to the machine.
- Stitch Machine Step 4, Blanket Stitch Tackdown.







STEP 9

- Stitch Machine Step 5, Orange Fabric Placement Stitch.
- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.



STEP 10

- Remove the paper from the back of the prepared applique to expose the adhesive surface.
- Position the applique, fabric side up, within the placement stitch, matching the cut edges with the stitching line.
- Finger press to secure.



- · Return the hoop to the machine.
- Stitch Machine Step 6, Blanket Stitch Tackdown.



ASSEMBLY



STEP 12

• Stitch the remaining steps per the thread chart.



STEP 13

- Remove the project from the hoop and any excess stabilizer from the project.
- Press face down on a Perfect Embroidery Press Cloth.



STEP 14

• The project is complete. Enjoy!




PRINTING INSTRUCTIONS



ATTENTION

When printing this document, any page scaling or page fitting options in your print dialog box must be turned OFF or set to NONE so that your files will print out at their actual size. Images not printed at actual size will not function as intended.



TO SAVE PAPER

Only print the desired image by navigating to the image's page, go to File > Print and select "Current page" in the print dialog box. Repeat for each desired image.

