

Product Usage Instructions

Fusible Woven

- Fusible Woven is intended for use under an entire project area, such as a full quilt block or full panel of a bag or garment item.
- Cut a piece of Fusible Woven CutAway stabilizer to the same size as the fabric to be lined.
- NOTE: If the fabric to be lined is larger than the Fusible Woven width, overlap pieces of Fusible Woven by approximately 1/8".
- Lay the item to be embroidered, wrong side up, on an ironing board.
- Place the Fusible Woven CutAway, fusible side down, on the wrong side of the item.
- Press the Fusible Woven CutAway with a medium iron (wool setting).
- Add any additional stabilizer needed to the section of the fabric to be embroidered.
- For very lightweight designs, such as redwork, Fusible Woven may be used on its own or in combination with a lightweight tearaway stabilizer.
- For more stitch intensive designs, add a layer of medium to heavy weight tearaway or cutaway stabilizer.

REMOVAL INSTRUCTIONS:

- NOTE: For most applications, it is recommended to leave Fusible Woven in place as you would a lining or interfacing.
- NOTE: When applied with adequate heat, Fusible Woven is permanently fused to the fabric and will not separate during washing or drying.

Removing from fabric after embroidery:

- Remove your embroidered item from the hoop.
- Lay the embroidered item with the stabilizer up on an ironing board.
- Gently heat the Fusible Woven CutAway with a medium iron to release the stabilizer.
- Carefully peel the excess Fusible Woven CutAway from the fabric around the embroidered item until you reach the edges of the stitching.
- Turn the item embroidered side up, and while lifting and folding the embroidered fabric out of the way, carefully trim the Fusible Woven CutAway stabilizer.