

Sewing Patches

#12721 / 3 Designs

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



12721-01 Sewing Machine Patch FSA

3.37 X 3.38 in. 85.60 X 85.85 mm 10,812 St.



12721-02 Tomato Pincushion Patch FSA

3.54 X 3.54 in. 89.92 X 89.92 mm 8,464 St.



12721-03 Spool & Thimble Patch FSA

3.83 X 3.35 in. 97.28 X 85.09 mm 8,046 St.

Listings below indicate color sample, stitching order and suggested thread color number. Most numbers indicate Isacord thread.

Colors beginning with 7 refer to Yenmet Metallic and 9 refer to Isacord Multicolor Variegated.

12721-01 Sewing Machine Patch FSA			
	Square Placement Stitch	2220	
	2. Cut Line and Tackdown	2220	
	3. Green Detail	5610	
	4. White Detail	0015	
	5. Blue Detail	4220	
	6. Charcoal Detail	4174	
	7 Cover Stitch	2220	

12721-02 Tomato Pincushion Patch FS	SA
1. Circle Placement Stitch	1220
2. Cut Line and Tackdown	1220
3. Pink Pinhead	2220
4. Red Cushions	1805
5. Green Detail	5610
6. White Detail	0015
7. Charcoal Detail	4174
8. Cover Stitch and Pinhead	1220
9. Linework and Pinhead	4220

12721-03 Spool & Thimble Patch FSA	
1. Hexagon Placement Stitch	422
Cut Line and Tackdown	422
3. Orange Detail	122
4. Gray Detail	013
5. White Detail	001
Cover Stitch and Blue Detail	422
7. Charcoal Detail	417
	1 1 1

Isacord Thread Colors Used in "Sewing Patches"

Collection #12721

0015 White2220 Tropicana0131 Smoke4174 Charcoal1220 Apricot4220 Island Green1805 Strawberry5610 Bright Mint



Sewing Patches

Instructions

General Freestanding Applique Guidelines

Supplies:

Embroidery Thread:

• Use the same embroidery thread in the bobbin as the needle. **Needles:**

- Use an Organ 80/12 Titanium needle for extended needle life. **Stabilizer:**
- Use water-soluble stabilizer or film water-soluble stabilizer.

General Applique Instructions

- 1. Hoop two layers of OESD AquaMesh Stabilizer.
- 2. Attach the hoop to the machine and select the design of your choice.
- 3. Stitch the Placement Stitch. Photo 1
- 4. Place a piece of applique fabric over the Placement Stitch so that it is completely covered.
- 5. Stitch the Cut Line & Tackdown stitch.
- 6. Carefully cut away the excess applique fabric. Photo 2
- 7. Stitch the remainder of the design and repeat for any remaining pieces. **Photo 3**
- 8. Remove the hoop from the machine and the design from the hoop.
- 9. Trim excess stabilizer from the design.
- 10. Rinse away remaining stabilizer and allow it to dry face down to prevernt curling.

Handy Hints

Drying:

 Freestanding pieces look best when left to dry with right side down. This will minimize the tendency for a piece to curl. Be sure to flatten the piece out entirely and allow ample time to dry.

