

Product Usage Instructions

Gentle Touch Backing

USING AS A BACKING:

- Cut a piece of Gentle Touch at least 1/2" larger than the design, or other area, to be covered. For best results, round any sharp corners.
- Place right side down with the back of the embroidery accessible on an ironing surface. For best results, use an OESD Perfect Embroidery Press Cloth.
- Position the Gentle Touch fusible (rough) side down over the back of the design completely covering the stitches and any remaining stabilizer.
- Gently press with an up and down motion using a setting warm enough to activate the adhesive, but not hot enough to melt the Gentle Touch. A wool setting is usually sufficient.
- All edges should be completely bonded to achieve a permanent fuse.

USING AS INTERFACING:

- Cut the Gentle Touch the same size as the collar, cuffs, or facings as needed.
- Place the wrong side of the area to be covered up on the ironing board.
- Place the fusible side (the side with the little dots) of the Gentle Touch down over the area that needs to be interfaced.
- Gently press with an up and down motion using a setting warm enough to activate the adhesive.
- Test on a sample piece prior to fusing to your project.

