

# Product Usage Instructions

## StabilStick TearAway Stabilizer

---

- Cut a piece of StabilStick approximately 2" larger than the hoop to be used.
- Hoop the piece of StabilStick with the paper side up.
- Use a pin or the OESD Loop and Tail Wand to score ONLY the protective paper.
- Remove the paper to expose the pressure sensitive adhesive.
- Position the item on the hooped StabilStick.
- Gently smooth the item to the adhesive without stretching or distorting the fabric.
- Embroider the item.

### **REMOVAL INSTRUCTIONS:**

- Remove your embroidered item from the hoop.
- Tear the stabilizer carefully away from the embroidery, supporting the embroidery stitches between the thumb and finger to avoid distorting the embroidery or tearing out stitches.



[www.OESD.com](http://www.OESD.com)