



**FREESTANDING
Victorian
House**



1

Design

Fits hoop sizes 5" x 7" and larger

THREAD LIST



Isacord Thread Colors

0015 White (2 spools)


*** Project instructions included after design list.**

Note: One spool of 1000 meter thread is adequate for the project unless otherwise noted.

DESIGNS

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

***Fabric Required**




12424-01 Front Wall FSA

Size Inches: Size mm: Stitch Count:
4.15 X 6.13 in. 105.41 X 155.7 mm 36,673 St.

- 1. Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. Lace..... 0015

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

***Fabric Required**




12424-02 Inner Wall FSA

Size Inches: Size mm: Stitch Count:
4.14 X 4.96 in. 105.16 X 125.98 mm 27,149 St.

- 1. Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. Lace..... 0015

***Fabric Required**




12424-03 Back Wall FSA

Size Inches: Size mm: Stitch Count:
4.15 X 6.13 in. 105.41 X 155.7 mm 38,966 St.

- 1. Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. Lace..... 0015

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

***Fabric Required**




12424-04 Left Wall FSA

Size Inches: Size mm: Stitch Count:
4.14 X 4.97 in. 105.16 X 126.24 mm 34,044 St.

- 1. Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. Lace..... 0015

***Fabric Required**



12424-05 Foundation 1 FSA

Size Inches: Size mm: Stitch Count:
4.15 X 5.12 in. 105.41 X 130.05 mm 11,321 St.


- 1. Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. Lace..... 0015

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

***Fabric Required**

12424-06 Right Roof FSA

Size Inches: Size mm: Stitch Count:
3.39 X 5.37 in. 86.11 X 136.4 mm 23,848 St.




- 1. Roof Placement Stitch..... 0015
- 2. Roof Cut Line and Tackdown 0015
- 3. Snow Placement Stitch 0015
- 4. Snow Cut Line and Tackdown 0015
- 5. Lace..... 0015

***Fabric Required**


12424-07 Left Roof FSA

Size Inches: Size mm: Stitch Count:
3.45 X 5.38 in. 87.63 X 136.65 mm 25,822 St.



- 1. Roof Placement Stitch..... 0015
- 2. Roof Cut Line and Tackdown 0015
- 3. Snow Placement Stitch 0015
- 4. Snow Cut Line and Tackdown 0015
- 5. Lace..... 0015

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.




12424-08 Chimney FSL

Size Inches: Size mm: Stitch Count:
4.68 X 2.44 in. 118.87 X 61.98 mm 16,938 St.

- 1. Single Color Design..... 0015

***Fabric Required**




12424-09 Front & Back Wing Wall FSA

Size Inches: Size mm: Stitch Count:
2.7 X 4.15 in. 68.58 X 105.41 mm 16,698 St.

- 1. Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. Lace..... 0015

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

***Fabric Required**




12424-10 Right Wall FSA

Size Inches: Size mm: Stitch Count:
3.27 X 5.2 in. 83.06 X 132.08 mm 26,942 St.

- 1. Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. Lace..... 0015

***Fabric Required**



12424-11 Wing Roof FSA

Size Inches: Size mm: Stitch Count:
3.8 X 4.53 in. 96.52 X 115.06 mm 20,797 St.

- 1. Roof Placement Stitch..... 0015
- 2. Roof Cut Line and Tackdown 0015
- 3. Snow Placement Stitch 0015
- 4. Snow Cut Line and Tackdown 0015
- 5. Lace..... 0015

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

***Fabric Required**



12424-12 Foundation 2 FSA

Size Inches: Size mm: Stitch Count:
2.7 X 3.41 in. 68.58 X 86.61 mm 5,341 St.

- 1. Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. Lace..... 0015

Stabilizers

- OESD AquaMesh WashAway
- OESD BadgeMaster WashAway
- OESD StabilStick CutAway

Fabrics/Textiles

- White cotton fabric 1/4 yard
- Note: Fabric sizes are estimates and may result in overage.

Notions & Tools

- OESD Alligator Clamps
- OESD Button Clips
- OESD Expert Embroidery Tape WashAway
- OESD Perfect Embroidery Press Cloth
- OESD Perfect Point and Press Tool
- Embroidery Needle Sharp 75/11

Isacord Thread Colors

- Per thread chart
- Match bobbin thread to top thread
- 0015 White (2 spools)

SUMMARY




Completed Size: 6 ¾" Tall, 6" x 4 ¾"

12424-01




Requires 1 Design

12424-02




Requires 1 Design

12424-03




Requires 1 Design

12424-04




Requires 1 Design

12424-05




Requires 1 Design

12424-06




Requires 1 Design

12424-07




Requires 1 Design

12424-08




Requires 1 Design

12424-09




Requires 2 Designs

12424-10




Requires 1 Design

12424-11



Requires 1 Design

12424-12



Requires 1 Design

Notes

The freestanding applique instructions, included in the collection, are general instructions. For demonstration purposes, a sample design that best demonstrates the technique is shown. Fabric and thread requirements will vary by design, but the general technique is the same.

All designs are stitched with matching thread in the top and bobbin.

For other designs in the collection, use the applique templates as a guide to the dimensions of the various applique pieces.

Note: Some thread colors in instructions have been changed or digitally enhanced for better visibility.

STEP 1

- Hoop one layer of AquaMesh and one layer of BadgeMaster for all designs.



STEP 2

- Adhere two layers of StabilStick CutAway to the wrong side of all applique fabrics to provide stiffness to the finished structure.
- Cut the prepared applique fabrics 1/4"-1/2" larger than the templates.




EMBROIDERY




STEP 3

- Load selected design into the machine.
- Example design is Front Wall FSA (12424-01).
- Thread the machine per the thread chart.
- Place hoop on the machine.




STEP 4

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Place the prepared applique fabric, right side up, completely covering the placement stitch.
- Tape in place to secure.




STEP 5

- Return the hoop to the machine.
- Stitch Machine Step 2, Cut Line and Tackdown.



STEP 6

- Remove the hoop from the machine, but NOT the project from the hoop.
- Trim the excess fabric as close to the cut line as possible. If the outermost stitches (cut line) are cut, the inner stitches (tackdown) will hold the applique in place.
- Tip: If the AquaMesh is cut or a hole is created while trimming the fabric, use OESD Expert Embroidery Tape WashAway as a patch.



STEP 7

- Return the hoop to the machine.
- Stitch Machine Step 3, Lace.
- Match the bobbin thread to the upper thread.
- When design is complete, remove the project from the hoop and trim the stabilizer 1/4" - 1/2" outside the design.



ASSEMBLY



STEP 8

- Rinse each piece in warm running water until the design is only slightly sticky.
- Lay face down on a non-stick surface to dry. Parchment paper or a cooling rack work well. This prevents the piece from curling.
- Press each piece, right side down, on a Perfect Embroidery Press Cloth.



STEP 9

- Using alligator clamps, attach the Victorian House Inner Wall (12424-02) to Victorian House Front Wall (12424-01) by pulling the three buttonettes along the right side of the front wall into the three eyelets along the edge of the inside wall.




ASSEMBLY




STEP 10

- Attach the Victorian House Left Wall (12424-04) to the Victorian House Front Wall (12424-01) by pulling the three buttonettes along the left side of the front wall into the three eyelets along the edge of the inside wall.



STEP 11

- Attach the Victorian House Front & Back Wing Wall (12424-09) to the Victorian House Inner Wall (12424-02) by pulling the three buttonettes from the front & back wing wall into the corresponding eyelets located on the inner wall.




ASSEMBLY




STEP 12

- Attach the Victorian House Right Wall (12424-10) to Victorian House Front & Back Wing Wall (12424-09) by pulling the three buttonettes along both the front and back wing walls into the three eyelets along both sides of the right wall.




STEP 13

- Finish the house by attaching the Victorian House Back Wall 12424-03 to both Victorian House Inner Wall (12424-02) and Victorian House Left Wall (12424-04) by pulling the three buttonettes along each side of the back wall into the three eyelets along both the inner and left wall edges.




STEP 14

- Construct the Victorian House Chimney (12424-08) by folding it into a square and pulling the three buttonettes from one side into the three eyelets along the opposite edge.



STEP 15

- Attach the Victorian House Chimney (12424-08) to the Victorian House Left Roof (12424-07) by pulling the four buttonettes of the chimney into the eyelets located at each corner of the small rectangular area located on the left roof.





ASSEMBLY



STEP 16

- Attach the Victorian House Right Roof (12424-06) to the Victorian House Left Roof (12424-07) by pulling the buttonettes into the four eyelets located along the edge of the right roof.



STEP 17

- Attach the Victorian House Right Roof (12424-06) to the Victorian House Inner Wall (12424-02) by pulling the three buttonettes along the upper edge of the inner wall into the three eyelets along the bottom edge of the right roof. Start with the center buttonette followed by the two end buttonettes.



ASSEMBLY



STEP 18

- Fold Victorian House Wing Roof (12424-11) into a V shape.




STEP 19

- Attach the Victorian House Wing Roof (12424-11) to Victorian House Right Roof (12424-06) by pulling the two buttonettes of the wing roof into the two eyelets on either side of the triangular area located on the right roof.



STEP 20

- Attach the Victorian House Wing Roof (12424-11) to Victorian House Right Roof (12424-06) by pulling the two buttonettes closest to the main building into the two eyelets of the wing roof.



STEP 21

- Then pull the two outermost buttonettes of the front and back wings into the two eyelets on the wing roof.



ASSEMBLY




STEP 20

- Attach the Victorian House Wing Roof (12424-11) to Victorian House Right Wall (12424-10) by pulling the four buttonettes lining the upper edge of the right wall into the four eyelets located along the outer edge of the wing roof.



STEP 23

- Continue attaching the main roof to the main building by pulling the remaining eleven buttonettes of the main building into the eleven eyelets located along the edges of the main roof.




ASSEMBLY




STEP 17

- Attach Victorian House Foundation 2 (12424-12) to the Victorian House Inner Wall (12424-02) by pulling the buttonette of foundation 2 into the one eyelet of the inner wall.



STEP 18

- Attach Victorian House Foundation 2 (12424-12) to Victorian House Front & Back Wall (12424-09) by pulling the buttonettes on each end of the foundation 2 into the one eyelet at the bottom center of the front and back wing walls.




ASSEMBLY



STEP 19

- Attach the Victorian House Foundation (12424-05) to Victorian House Inner Wall (12424-02) by pulling the buttonette on the foundation into the one eyelet remaining on the inner wall.



ASSEMBLY



FINISHING TOUCHES

- The Victorian house is complete. Enjoy.
- Add tea lights or pixie lights to create a glow.



Stabilizer

- OESD AquaMesh
- OESD BadgeMaster

Notions/Tools

- 80/12 Embroidery Ballpoint Titanium needle for extended needle life
- OESD Alligator Clamps
- OESD Button Clips
- OESD Perfect Point and Press Tool

Isacord Thread Colors

- All OESD designs are digitized with Isacord 40 wt. polyester thread as the top thread and in the bobbin.
- Refer to the thread chart for color specifications.
- Match bobbin thread color to the top thread.

Instructions

Step 1 - Hoop

For FSL structures, hoop one layer of OESD AquaMesh and one layer of OESD BadgeMaster. BadgeMaster contains more starch so, combined with the AquaMesh, the lace is more rigid. For other FSL, where a softer lace is desired, hoop two layers of AquaMesh.

Step 2 - Embroider

Stitch the design per the thread chart with matching thread in the bobbin at each color change. When complete, remove from the hoop and trim away excess stabilizer about 1/4"-1/2" from the stitching.

Step 3 - Rinse

Rinse remaining stabilizer out in warm running water. For stiffer lace and FSL structures, DO NOT rinse away all of the stabilizer. The lace should be just slightly tacky. For softer lace, rinse until all traces of the stabilizer are removed.

Step 4 - Dry

Lay right side down flat on a non-stick surface, such as a cooling rack, parchment paper or Teflon sheet. This minimizes the tendency for the lace to curl. Let the pieces dry completely before proceeding with any assembly.

Step 5 - Press

Once completely dry, press right side down on a OESD Perfect Embroidery Press Cloth.

Step 6 - Assemble Structure

Note: Specific assembly instructions for a design/collection may be found in the thread chart pdf following the individual design color charts.

Lace must be COMPLETELY DRY before assembly. Wetting the buttonettes or eyelets to assemble is not recommended and may result in them stretching and coming "unbuttoned" when dry.

Use a pair of OESD Alligator Clamps to insert the buttonettes into the eyelets. Insert the tip of the OESD Alligator Clamps into the eyelet, grasp the buttonette and pull through the eyelet. Alternatively, use a stiletto or tweezers to push the buttonette through the eyelet.

Helpful Tips

Limp Lace

If the design is not stiff enough, press the lace pieces on the wrong side while applying spray starch. After ironing, spray again with starch and allow to dry completely. This will stiffen the lace pieces nicely and aid in construction. Or easily re-stiffen by diluting some stabilizer scraps in water (or use liquid starch) and dipping the item in the solution. Lay flat to dry.

Eyelets Too Small

If any of the eyelets appear closed or too small to penetrate with Alligator Clamps, they may be stretched by inserting the small end of the OESD Perfect Point and Press Tool into the eyelet opening and stretching it open wide enough to accommodate the OESD Alligator Clamps.

Button Clips

During the assembly process, some structures pull on buttonettes that have already been inserted and could pull them out altogether. Putting a Button Clip on the assembled buttonette will keep it in position during the assembly process. Remove the Button Clips when the assembly is complete.


Alternative Construction Option

In some cases, the buttonettes may be pulled to the inside of a project, instead of being visible on the outside. Insert the OESD Alligator Clamps through the eyelet from the wrong, or inside, of the lace and grasp the corresponding buttonette. Pull the buttonette to the wrong side of the lace.

Pulling the buttonettes to the inside may cause stress on the ones already done. Button clips may be placed on the completed buttonette(s) to prevent them from pulling out of the eyelet during construction.


ATTENTION

When printing this document, any page scaling or page fitting options in your print dialog box must be turned OFF or set to NONE so that your files will print out at their actual size. Images not printed at actual size will not function as intended.



TO SAVE PAPER





Only print the desired image by navigating to the image's page, go to File > Print and select "Current page" in the print dialog box. Repeat for each desired image.



APPLIQUE PATTERNS








Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



APPLIQUE PATTERNS





Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



APPLIQUE PATTERNS








Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



APPLIQUE PATTERNS





Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



APPLIQUE PATTERNS







Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



MIRRORED PATTERNS








Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



MIRRORED PATTERNS





Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



MIRRORED PATTERNS








Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



MIRRORED PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



MIRRORED PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.

