










Note: Use DesignWorks Software to edit PaintWork and CrystalWork designs, including rescaling, rotating, and mirror imaging.

 <p>12448-01_CW Applique Bluebird 3.70 X 4.46 in. 93.98 X 113.28 mm 1,800 St.</p>	 <p>12448-01_CWA_A Applique Bluebird CutWork 1 2.78 X 3.91 in. 70.61 X 99.31 mm 1,500 St.</p>	 <p>12448-01_CWA_B Applique Bluebird CutWork 2 2.13 X 1.67 in. 54.10 X 42.42 mm 700 St.</p>
 <p>12448-02_CW Applique Swirls 3.81 X 8.24 in. 96.77 X 209.30 mm 3,200 St. L</p>	 <p>12448-02_CWA_A Applique Swirls CutWork 1 4.20 X 7.87 in. 106.68 X 199.90 mm 3,800 St. L</p>	 <p>12448-02_CWA_B Applique Swirls CutWork 2 2.52 X 3.78 in. 64.01 X 96.01 mm 1,500 St.</p>
 <p>12448-03_CW Applique Tea Time 3.88 X 7.23 in. 98.55 X 183.64 mm 1,800 St. L</p>	 <p>12448-03_CWA_A Applique Tea Time CutWork 1 3.13 X 5.04 in. 79.50 X 128.02 mm 2,500 St. L</p>	 <p>12448-03_CWA_B Applique Tea Time CutWork 2 2.24 X 2.96 in. 56.90 X 75.18 mm 1,500 St.</p>

Note: Use DesignWorks Software to edit PaintWork and CrystalWork designs, including rescaling, rotating, and mirror imaging.

 <p>12448-04_DW Applique Paisley Thread & PaintWork 3.04 X 6.73 in. 77.22 X 170.94 mm 3,600 St. L</p>	 <p>12448-04_CR Applique Paisley CrystalWork 2.06 X 4.60 in. 52.32 X 116.84 mm</p>	 <p>12448-04_CWA Applique Paisley CutWork 3.12 X 6.28 in. 79.25 X 159.51 mm 2,400 St. L</p>
 <p>12448-05_DW Applique Decorative Fish Thread & PaintWork 4.59 X 7.76 in. 116.59 X 197.10 mm 10,800 St. L</p>	 <p>12448-05_CR Applique Decorative Fish CrystalWork 3.23 X 6.51 in. 82.04 X 165.35 mm L</p>	 <p>12448-05_CWA Applique Decorative Fish CutWork 4.77 X 7.34 in. 121.16 X 186.44 mm 3,300 St. L</p>
 <p>12448-06_DW Jumbo Applique Elephant Thread & PaintWork 7.50 X 9.57 in. 190.50 X 243.08 mm 18,800 St. L</p>	 <p>12448-06_CR Jumbo Applique Elephant CrystalWork 7.28 X 8.11 in. 184.91 X 205.99 mm L</p>	 <p>12448-06_CWA Jumbo Applique Elephant CutWork 7.67 X 9.11 in. 194.82 X 231.39 mm 6,600 St. L</p>

Note: Use DesignWorks Software to edit PaintWork and CrystalWork designs, including rescaling, rotating, and mirror imaging.



12448-07_PW PaintWork Rearing Horse
4.81 X 5.72 in.
122.17 X 145.29 mm
6,700 St. L



12448-08_PW PaintWork Henna
4.69 X 6.98 in.
119.13 X 177.29 mm
4,700 St. L



12448-09_PW PaintWork Flowing Hair
7.65 X 10.17 in.
194.31 X 258.32 mm
14,300 St. L



12448-10_CR Crystal Star
CrystalWork
3.28 X 3.89 in.
83.31 X 98.81 mm



12448-11_CR Crystal Bow
CrystalWork
3.46 X 5.04 in.
87.88 X 128.02 mm
L



12448-12_CR Crystal Crown
CrystalWork
4.51 X 4.25 in.
114.55 X 107.95 mm



DesignWorks Sampler 2

#12448DW / 12 Designs / 24 Files

Listings below indicate color sample, paint and/or crystal punch order, suggested pen and/or crystal colors, and crystal stone sizes.

12448-01_CW Applique Bluebird

■	1. Body Placement Stitch	3353
■	2. Body Tackdown	3353
■	3. Body Cover Stitch	3353
■	4. Wing Placement Stitch	3641
■	5. Wing Tackdown	3641
■	6. Wing Cover Stitch	3641
■	7. White Eye & Linework	0015

12448-01_CWA_A Applique Bluebird CutWork 1

■	1. Basting Stitch	3600
■	2. Bernina CutWork Accessory Cut 1	Cut 1
■	3. Bernina CutWork Accessory Cut 2	Cut 2
■	4. Bernina CutWork Accessory Cut 3	Cut 3
■	5. Bernina CutWork Accessory Cut 4	Cut 4

12448-01_CWA_B Applique Bluebird CutWork 2

■	1. Basting Stitch	3600
■	2. Bernina CutWork Accessory Cut 1	Cut 1
■	3. Bernina CutWork Accessory Cut 2	Cut 2
■	4. Bernina CutWork Accessory Cut 3	Cut 3
■	5. Bernina CutWork Accessory Cut 4	Cut 4

12448-02_CW Applique Swirls

■	1. Pink Swirls Placement Stitch	2550
■	2. Pink Swirls Tackdown	2550
■	3. Pink Swirls Cover Stitch	2550
■	4. Orange Swirls Placement Stitch	1102
■	5. Orange Swirls Tackdown	1102
■	6. Orange Swirls Cover Stitch	1102

12448-02_CWA_A Applique Swirls CutWork 1

■	1. Basting Stitch	3600
■	2. Bernina CutWork Accessory Cut 1	Cut 1
■	3. Bernina CutWork Accessory Cut 2	Cut 2
■	4. Bernina CutWork Accessory Cut 3	Cut 3
■	5. Bernina CutWork Accessory Cut 4	Cut 4

12448-02_CWA_B Applique Swirls CutWork 2

■	1. Basting Stitch	3600
■	2. Bernina CutWork Accessory Cut 1	Cut 1
■	3. Bernina CutWork Accessory Cut 2	Cut 2
■	4. Bernina CutWork Accessory Cut 3	Cut 3
■	5. Bernina CutWork Accessory Cut 4	Cut 4

12448-03_CW Applique Tea Time

■	1. Teapot Placement Stitch	3641
■	2. Teapot Tackdown	3641
■	3. Teapot Cover Stitch & Placement Stitch for Teapot Top & Teacup	3641
■	4. Top of Teapot & Teacup Tackdown	3641
■	5. Teapot Top & Teacup Cover Stitch and Linework	3641

12448-03_CWA_A Applique Tea Time CutWork 1

■	1. Basting Stitch	3600
■	2. Bernina CutWork Accessory Cut 1	Cut 1
■	3. Bernina CutWork Accessory Cut 2	Cut 2
■	4. Bernina CutWork Accessory Cut 3	Cut 3
■	5. Bernina CutWork Accessory Cut 4	Cut 4

12448-03_CWA_B Applique Tea Time CutWork 2

■	1. Basting Stitch	3600
■	2. Bernina CutWork Accessory Cut 1	Cut 1
■	3. Bernina CutWork Accessory Cut 2	Cut 2
■	4. Bernina CutWork Accessory Cut 3	Cut 3
■	5. Bernina CutWork Accessory Cut 4	Cut 4

12448-04_CR Applique Paisley CrystalWork

■	1. SS6 (34 Rhinestones)	Crystal
---	-------------------------	---------

12448-04_CWA Applique Paisley CutWork

■	1. Basting Stitch	3600
■	2. Bernina CutWork Accessory Cut 1	Cut 1
■	3. Bernina CutWork Accessory Cut 2	Cut 2
■	4. Bernina CutWork Accessory Cut 3	Cut 3
■	5. Bernina CutWork Accessory Cut 4	Cut 4

12448-04_DW Applique Paisley Thread & PaintWork

■	1. Paisley Placement Stitch	3750
■	2. Paisley Tackdown	3750
■	3. Paisley Cover Stitch	3750
■	4. Blue Details PaintWork	4600-3

12448-05_CR Applique Decorative Fish

■	1. SS6 (14 Rhinestones)	Crystal
■	2. SS10 (24 Rhinestones)	Crystal
■	3. SS16 (7 Rhinestones)	Crystal

12448-05_CWA Applique Decorative Fish CutWork

■	1. Basting Stitch	3600
■	2. Bernina CutWork Accessory Cut 1	Cut 1
■	3. Bernina CutWork Accessory Cut 2	Cut 2
■	4. Bernina CutWork Accessory Cut 3	Cut 3
■	5. Bernina CutWork Accessory Cut 4	Cut 4

12448-05_DW Applique Decorative Fish Thread & PaintWork

■	1. Fish Placement Stitch	0520
■	2. Fish Tackdown	0520
■	3. Fish Cover Stitch	0520
■	4. Light Blue Details PaintWork	4600-10
■	5. Orange Details PaintWork	4600-6
■	6. Brown Details PaintWork	4600-7

12448-06_CR Jumbo Applique Elephant

■	CrystalWork	
■	1. SS6 (17 Rhinestones)	Crystal
■	2. SS10 (23 Rhinestones)	Crystal
■	3. SS16 (40 Rhinestones)	Crystal

12448-06_CWA Jumbo Applique Elephant CutWork

■	1. Basting Stitch	3600
■	2. Bernina CutWork Accessory Cut 1	Cut 1
■	3. Bernina CutWork Accessory Cut 2	Cut 2
■	4. Bernina CutWork Accessory Cut 3	Cut 3
■	5. Bernina CutWork Accessory Cut 4	Cut 4

12448-06_DW Jumbo Applique Elephant Thread & PaintWork

■	1. Elephant Placement Stitch	3040
■	2. Elephant Tackdown	3040
■	3. Elephant Cover Stitch	3040
■	4. Linework on Feet & Tail	2640
■	5. Rose Details PaintWork	4600-9
■	6. Light Blue Details PaintWork	4600-10
■	7. Rose Details PaintWork	4600-9

12448-07_PW PaintWork Rearing Horse

■	1. Black Details PaintWork	4600-1
---	----------------------------	--------

12448-08_PW PaintWork Henna

■	1. Brown Details PaintWork	4600-7
---	----------------------------	--------

12448-09_PW PaintWork Flowing Hair

■	1. Light Blue Details PaintWork	4600-10
■	2. Red Details PaintWork	4600-2
■	3. Purple Details PaintWork	4600-8
■	4. Black Details PaintWork	4600-1

12448-10_CR Crystal Star CrystalWork

■	1. SS6 (10 Rhinestones)	Crystal
■	2. SS10 (56 Rhinestones)	Crystal
■	3. SS16 (16 Rhinestones)	Crystal

12448-11_CR Crystal Bow CrystalWork

■	1. SS6 (57 Rhinestones)	Crystal
■	2. SS10 (22 Rhinestones)	Crystal
■	3. SS16 (87 Rhinestones)	Crystal

12448-12_CR Crystal Crown CrystalWork

■	1. SS6 (63 Rhinestones)	Crystal
■	2. SS10 (40 Rhinestones)	Crystal
■	3. SS16 (69 Rhinestones)	Crystal

NOTE: Paint colors listed (beginning with 4600) refer to Edding Textile Pens, style 4600. The number following 4600 is the recommended pen color.







It is a violation of Copyright law to make and distribute copies of software or artwork. Software is licensed to the original purchaser for use at one location. ©2012 OESD, LLC. All rights reserved.

CRYSTALWORK INSTRUCTIONS:



1. Remove upper thread from the machine.
2. Attach the Straight Stitch/CutWork Stitch Plate for your machine.
3. Remove the needle and replace with the correct size punch tool (SS6, SS10, SS12, SS16 as noted on the Color Bar of the machine or in the crystal chart for the design collection) with the flat side toward the back. Tighten the needle clamp.
4. Attach Presser Foot #48.
5. Place the CrystalWork container on the stitch plate with the center positioning pin in the rear hole of the stitch plate.
6. Attach the punch plate (same size as the punch tool used) on top of the container so that it sits flush with the top.
7. Lower the punch tool by turning the handwheel to check that the container lines up correctly. **See Photo 1**
8. Hoop parchment paper up-side down and trim all excess from edges. **See Photos 2 and 3**
9. Cut a piece of rhinestone template material slightly larger than the design. Remove backing from the template material and place the sticky side down on the top of the parchment paper in the center of the hoop. **See Photo 4**
10. Place hoop on machine and use your machine's check feature to ensure that the template material is positioned correctly. Punch the first color change.

Note: The machine will prompt you when the container is full and needs to be emptied. However, you may also wish to empty the container between color changes. ANY time you remove the container for cleaning, be sure to repeat Step 7 to ensure that the container is positioned properly. Check the back of the parchment paper between color changes also to remove any stray dots that may be stuck to the paper.

11. If more than one size crystal is used in the design, replace the punch tool and the punch plate on the top of the container with sizes to correspond with the size shown on the Color Bar of the machine. Repeat this process as needed until the design is finished. **See Photo 5**
12. Carefully peel the rhinestone template material away from the parchment paper and place on a piece of rhinestone template backboard. Smooth into place.
13. Pour the largest size of crystals used in the design over the template and use a small rhinestone brush to push them into place. **See Photos 6 and 7**
14. Make sure that all holes of that size are filled, and that all crystals are facing upright.
15. Repeat Steps 13 and 14 for any additional sizes, continuing with the next largest size and progressing to the smallest size.
16. Once all holes in the template are filled with the correct size crystals, check to ensure that all crystals are facing up and that there are no stray crystals. **See Photo 8**



17. Cut a piece of rhinestone application tape slightly larger than the design.
18. Remove the backing and place tape sticky side down over the crystal template. **See Photo 9**
19. Smooth application tape over the top of each crystal using your fingertips or the rhinestone brush to ensure that all crystals are adhered to the tape.
20. Slowly peel transfer tape away from the template. The crystals should come up adhered to the tape. **See Photo 10**
If individual crystals are loose or missing, lay the tape carefully back down and re-adhere crystals.
21. Position the transfer tape with the crystals sticky side down onto your project. **See Photo 11**
22. Place a press cloth over the transfer tape and press firmly with a hot iron for approximately 15 seconds. If the transfer is larger than the iron, move the iron to another area and repeat. **NOTE:** Time and temperature given here are meant as guidelines only. Refer to instructions from the crystal manufacturer for best results.
23. Allow the transfer to cool completely before peeling the transfer tape away. **See Photo 12**



PAINTWORK INSTRUCTIONS

1. Remove the upper thread and needle from the machine.
2. Attach the Straight Stitch/CutWork Stitch Plate to the machine.
3. Open the clamping lever on the PaintWork tool and slide the appropriate pen adaptor into the shaft of the tool. Close the clamping lever.
4. Attach the PaintWork tool over the presser foot holder cone and secure with the lever.
5. Prior to hooping, iron the fabric to remove any wrinkles. The fabric must be smooth and hooped securely in order to ensure proper working of the tool.
6. Hoop your project using the appropriate stabilizing method.
 - Method A:**
 - a. Hoop a piece of Stabil-Stick Cut Away or Stabil-Stick Tear Away by itself in the hoop.
 - b. Score and remove the paper.
 - c. Place the fabric to be painted over the sticky surface with right side up. Gently smooth into position. For best results, the stabilizer should be adhered to as much area of the fabric as possible.
 - Method B**
 - a. Spray stabilizer of your choice with a generous amount of temporary spray adhesive.
 - b. Place the sprayed side of the stabilizer on the wrong side of the fabric. Hoop all layers as one unit.
7. Attach the hoop to the machine.
8. Swing the pen guard down. Release the clamping lever and insert the appropriate pen with a slight twisting motion until the tip just touches the pen guard. Close the clamping lever. The pen should now be held firmly in place. **NOTE:** Although there should be some pressure against the pen as it is inserted, do not use excessive force without supporting the PaintWork tool.
9. Swing the pen guard up and start painting using the Start / Stop button on the machine. **NOTE:** It is advisable to hoop a test piece of fabric to test for pen pressure prior to the painting on the actual project. An alternative to this is to cut a hoop sized piece of Stabil-Stick, remove the paper from the entire back, and place the Stabil-Stick over the hooped project. Start the machine and paint for a few seconds. Adjust the pen pressure as needed to achieve the look you desire. (**See Photo 1**) Turning the dial counter-clockwise decreases the pressure. Turning the dial clockwise increases the pressure. When you have achieved the desired effect, remove the Stabil-Stick from the top and re-start the design from the beginning.
10. When the first color is finished, swing the pen guard down. Open the clamping lever and remove the pen.
11. Clean the pen guard between color changes and allow fabric to dry between color changes to avoid mixing colors. **Tip:** To help guarantee colors will not mix, remove the hoop from the machine, but not the fabric from the hoop. Use a small, applique iron to heat the color. Replace the hoop and continue your design.
12. Refer to the color information on the machine's screen and insert a second pen following steps above if needed. **Tip:** after raising the pen guard, wipe the tip of the pen with a white cloth before starting the color. **See Photo 2**
13. Use an Iron to heat set the painted fabric following pen manufacturer's instructions.



CUTWORK INSTRUCTIONS:

1. Cut the appliqué fabric slightly larger than the appliqué shape.
2. For best cutting results, back the fabric with a double-sided permanent adhesive appliqué product such as Lite Steam-A-Seam 2. Apply according to manufacturer's instructions.
3. Attach the Straight Stitch/CutWork Stitch Plate for your machine.
4. Center and sandwich 1 - 4 layers of the appliqué fabric backed with the appliqué product with fabric right side up between two layers of a very firm stiff stabilizer such as Hydro-Stick TearAway stabilizer (used dry). **See Photo 1 & 2** NOTE: if cutting more than 4 layers, hoop the stabilizer alone and stack the layers in the center of the hoop.
5. Attach the hoop and stitch the Basting Stitch from the design. **See Photo 3**
6. When the Color Bar on the screen reads "Cut 1", remove the needle and thread from the machine and insert the CutWork Tool with the flat side toward the back. Tighten the needle clamp.
7. Attach Foot #44C to the machine.
8. Ensure that the dial on the front of the CutWork Accessory reads "1" and start the machine.
9. When the Color Bar on the machine reads "Cut 2", turn the dial on the accessory to "2" and proceed.
10. When the Color Bar reads "Cut 3", turn the dial to "3" and cut.
11. When the Color Bar reads "Cut 4", turn the dial to "4" and cut.
12. Once the design is finished, gently separate the cut pieces. If needed, use small scissors or a surgical seam ripper to clip any threads that were not cut. **See Photo 4**
13. Your appliqué pieces are now ready to be used during the stitching of the corresponding design. **See Photo 5**



PHOTO 1



PHOTO 2




PHOTO 3



PHOTO 4




PHOTO 5

APPLIQUE INSTRUCTIONS

1. Hoop the background fabric with the appropriate stabilizer and stitch the Placement Stitch. **See Photo 6**
2. Remove the hoop from the machine, but do not remove the fabric from the hoop.
3. For the corresponding appliqué piece, if using an appliqué adhesive product (such as Lite Steam-A-Seam 2), remove the paper backing from the back of the appliqué. Carefully position the shape within the stitched lines. Affix the appliqué piece in place. **See Photo 7**
4. Re-attach the hoop to the machine and continue stitching the design. **See Photo 8** NOTE: If the design has more than one appliqué piece, repeat this process as needed until the design is finished.




PHOTO 6



PHOTO 7



PHOTO 8



DesignWorks Sampler 2

Instructions

GENERAL INSTRUCTIONS FOR USING MULTIPLE DESIGNWORKS COMPONENTS IN ONE DESIGN:

1. Cut out any appliqué shapes using the CutWork tool and the CutWork appliqué files prior to stitching the appliqué design. These file(s) are denoted by _CWA at end of file name. If a particular design has more than one CutWork shape, they will be denoted as _CWA_A, _CWA_B, etc.
2. Refer to the color information bar on your machine or your design instructions to determine the order in which you use traditional machine embroidery (needle and thread) or the PaintWork tool. PaintWork files are denoted by _PW at the end of a file name.
3. Create any CrystalWork templates using the CrystalWork files and the CrystalWork tool following the CrystalWork Instructions. These files are denoted by _CR at the end of the file name. The templates can be created either before or after the design is stitched, but the crystals will be applied after the embroidery and/or paint is completed.