



**FREESTANDING
Cottage with
Fence**



1

Designs

Fits hoop sizes 5" x 7" and larger

THREAD LIST



Isacord Thread Colors

0015 White (2 spools)

***Project instructions included after design list**

Note: One spool of 1000 meter thread is adequate for the project unless otherwise noted.

DESIGNS


Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

***Fabric Required**

12467-01 Front Wall FSA


Size Inches: Size mm: Stitch Count:
3.23 X 4.8 in. 82.04 X 121.92 mm 26,954 St.

- 1. Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. Lace..... 0015



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

***Fabric Required**




12467-02 Back Wall FSA

Size Inches: Size mm: Stitch Count:
3.24 X 4.81 in. 82.3 X 122.17 mm 29,161 St.

- 1. Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. Lace..... 0015

***Fabric Required**




12467-03 Side Wall FSA

Size Inches: Size mm: Stitch Count:
4.06 X 5.09 in. 103.12 X 129.29 mm 28,724 St.

- 1. Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. Lace..... 0015

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.


***Fabric Required**



12467-04 Chimney Wall FSA

Size Inches: Size mm: Stitch Count:
4.06 X 5.09 in. 103.12 X 129.29 mm 30,351 St.

- 1. Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. Lace..... 0015



12467-05 Chimney FSL

Size Inches: Size mm: Stitch Count:
3.91 X 5.89 in. 99.31 X 149.61 mm 30,463 St.


- 1. Lace..... 0015

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

***Fabric Required**

12467-06 Foundation FSA

Size Inches: Size mm: Stitch Count:
4.77 X 4.19 in. 121.16 X 106.43 mm 11,632 St.




- 1. Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. Lace..... 0015

***Fabric Required**

12467-07 Front Roof FSA

Size Inches: Size mm: Stitch Count:
4.33 X 5.19 in. 109.98 X 131.83 mm 29,965 St.




- 1. Roof Placement Stitch..... 0015
- 2. Roof Cut Line and Tackdown 0015
- 3. Snow Placement Stitch 0015
- 4. Snow Cut Line and Tackdown 0015
- 5. Lace..... 0015

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

***Fabric Required**

12467-08 Back Roof FSA

Size Inches: Size mm: Stitch Count:
3.35 X 5.18 in. 85.09 X 131.57 mm 23,628 St.



- 1. Snow Placement Stitch 0015
- 2. Snow Cut Line and Tackdown 0015
- 3. Roof Placement Stitch..... 0015
- 4. Roof Cut Line and Tackdown 0015
- 5. Lace..... 0015

12467-09 Porch Floor FSL

Size Inches: Size mm: Stitch Count:
4.43 X 1.42 in. 112.52 X 36.07 mm 7,879 St.




- 1. Lace..... 0015

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

12467-10 Pillars FSL

Size Inches: Size mm: Stitch Count:
3.95 X 3.07 in. 100.33 X 77.98 mm 23,016 St.


1. Lace..... 0015



12467-11 Fence FSL

Size Inches: Size mm: Stitch Count:
3.18 X 1.01 in. 80.77 X 25.65 mm 8,702 St.

1. Lace..... 0015



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



12467-12 Arch FSL

Size Inches: Size mm: Stitch Count:
0.77 X 6.04 in. 19.56 X 153.42 mm 15,376 St.

1. Lace..... 0015

COLLECTION SUPPLIES



Stabilizers

- OESD AquaMesh WashAway
- OESD BadgeMaster WashAway
- OESD StabilStick CutAway

Fabrics/Textiles

- White cotton fabric 1/4 yard
- Note: Fabric sizes are estimates and may result in overage.

Notions & Tools

- OESD Alligator Clamps
- OESD Button Clips
- OESD Embroidery Tape WashAway
- OESD Perfect Embroidery Press Cloth
- OESD Perfect Point and Press Tool
- Embroidery Needle Sharp 75/11

Isacord Thread Colors


- Per thread chart
- Match bobbin thread to top thread
- 0015 White (2 spools)

SUMMARY




Completed Size: 5 3/4" Tall, 5" x 5" square

12467-01



Requires 1 Design

12467-02




Requires 1 Design

12467-03




Requires 1 Design

12467-04




Requires 1 Design

12467-05




Requires 1 Design

12467-06




Requires 1 Design

12467-07




Requires 1 Design

12467-08




Requires 1 Design

12467-09




Requires 1 Design

12467-10




Requires 1 Design

12467-11



Requires 1 Design

12467-12



Requires 1 Design

Notes

The freestanding applique instructions, included in the collection, are general instructions. For demonstration purposes, a sample design that best demonstrates the technique is shown. Fabric and thread requirements will vary by design, but the general technique is the same.

All designs are stitched with matching thread, top and bobbin.

For other designs in the collection, use the applique templates as a guide to the dimensions of the various applique pieces.

Note: Some thread colors in instructions have been changed or digitally enhanced for better visibility.

STEP 1

- Hoop one layer of AquaMesh and one layer of BadgeMaster for all designs.



STEP 2

- Adhere two layers of StabilStick CutAway to the wrong side of all applique fabrics to provide stiffness to the finished structure.
- Cut the prepared applique fabrics 1/4" - 1/2" larger than the templates.




EMBROIDERY



STEP 3

- Load selected design into the machine.
- Example design is 12467-04.
- Thread the machine per the thread chart.
- Place hoop on the machine.
- Stitch Machine Step 1, Placement Stitch.




STEP 4

- Remove the hoop from the machine, but NOT the project from the hoop.
- Lay the hoop on a flat surface.
- Completely cover the placement stitch with the prepared fabric.
- Tape in place to secure.



STEP 5

- Return the hoop to the machine.
- Stitch Machine Step 2, Cut Line and Tackdown.



STEP 6

- Remove the hoop from the machine, but NOT the project from the hoop.
- Trim the excess fabric as close to the cut line stitching as possible.
- Note: If the outermost row of stitching (cut line) is accidentally cut, the inner stitches (tackdown) will hold the applique in place.
- Tip: If the OESD AquaMesh is cut or a hole is created while trimming the fabric, use OESD Expert Embroidery Tape WashAway as a patch.



STEP 7

- Return the hoop to the machine.
- Stitch Machine Step 3, Lace.
- Return the hoop to the machine and stitch the remaining machine steps according to the thread chart.
- Remember to match the bobbin thread to the upper thread colors where indicated.
- Stitch all required designs.
- When design is complete, remove the project from the hoop and trim the stabilizer 1/4" - 1/2" outside the design.
- Note: Designs 12467-05, 12467-09, 12467-10, 12467-11 and 12467-12 are Lace only, no applique. Fabric is not required. Follow General Lace Instructions.



ASSEMBLY




STEP 8

- Rinse each piece in warm running water until the design is only slightly sticky.
- Lay face down on a non-stick surface to dry.
- Tip: Parchment paper or a cooling rack work well. This prevents the piece from curling.
- Press each piece, right side down, on a Perfect Embroidery Press Cloth.



STEP 9

- Use alligator clamps to attach the Front Wall FSA (12467-01) to the Chimney Wall FSA (12467-04) by pulling the three buttonettes along the right side of the front wall into the three eyelets of the chimney wall.




ASSEMBLY




STEP 10

- Repeat this process to attach the Front Wall FSA (12467-01) to the Side Wall FSA (12467-03).



STEP 11

- Attach the Back Wall FSA (12467-02) to both Side Wall FSA (12467-03) and Chimney Wall FSA (12467-04) by pulling the three buttonettes on back wall into the three eyelets on both the side wall and chimney wall.




ASSEMBLY




STEP 12

- Attach Porch Floor FSL (12467-09) to Pillars FSL (12467-10) by pulling the two buttonettes on each end of the floor into the two eyelets on each of the pillars.




STEP 13

- Attach the porch unit to the Front Wall FSA (2467-01) by pulling the two buttonettes of the porch into the two eyelets along the bottom of the front wall.



STEP 14

- Pull the single buttonette on the short edge of each pillar into the single eyelet on each edge of the front wall.




STEP 15

- Attach Front Roof FSA (12467-07). Starting at the top, pull the two buttonettes on the Side Wall FSA (12467-03) into the two eyelets on the left side of the front roof.




STEP 16

- Attach the Chimney FSL (12467-05) to Chimney Wall FSA (12467-04) by pulling the six buttonettes of the chimney into the six eyelets on the chimney wall. Leave the chimney top unbuttoned.





STEP 17

- Attach Back Roof FSA (12467-08) to Front Roof FSA (12467-07) by pulling the four buttonettes on the top of the front roof into the coordinating eyelets.



STEP 18

- Slide chimney into the slots on both roofs.



STEP 19

- Attach the one buttonette inside the chimney area on chimney wall into the one eyelet on back roof.



ASSEMBLY



STEP 20

- Continue pulling buttonettes along chimney wall, across the back wall and up the side wall into the corresponding eyelets.



STEP 21


- Complete chimney by pulling the two buttonettes at the top into the two eyelets at the top.



ASSEMBLY

STEP 22

- Attach the 4 foundation buttonettes to the corresponding eyelets on each wall.




STEP 23

- Note: The Arch FSL (12467-12) is formed with the “wrong side” outward. This is done this way, so the stone foot path is presented with the “right side” up and so that the trellis archway stands upright correctly.
- Attach the two buttonettes to the corresponding eyelets.



STEP 24

- Fence FSL (12467-11) should be dried as flat as possible. Bend the tabs at a 90-degree angle to create supports. Bend fence panels at the hinge line to create corner pieces.



STEP 25

- Tip: If desired, sew the fence panels together for increased stability, or leave them as individual panels for more versatility.
- Line up the pieces to connect.
- Thread the sewing machine with matching thread in the top and bobbin.
- Tip: An open toe or edge stitch foot is helpful.
- Stitch together using a multi-step zigzag stitch (also known as a serpentine stitch).
- Back stitch at the beginning and end to secure.
- Trim thread tails.
- Fold and press to shape.



FINISHING TOUCHES

- The cottage with fence is complete. Enjoy.
- Add tea lights or pixie lights to create a glow.



Stabilizer

- OESD AquaMesh
- OESD BadgeMaster

Notions/Tools

- 80/12 Embroidery Ballpoint Titanium needle for extended needle life
- OESD Alligator Clamps
- OESD Button Clips
- OESD Perfect Point and Press Tool

Isacord Thread Colors

- All OESD designs are digitized with Isacord 40 wt. polyester thread as the top thread and in the bobbin.
- Refer to the thread chart for color specifications.
- Match bobbin thread color to the top thread.

Instructions

Step 1 - Hoop

For FSL structures, hoop one layer of OESD AquaMesh and one layer of OESD BadgeMaster. BadgeMaster contains more starch so, combined with the AquaMesh, the lace is more rigid. For other FSL, where a softer lace is desired, hoop two layers of AquaMesh.

Step 2 - Embroider

Stitch the design per the thread chart with matching thread in the bobbin at each color change. When complete, remove from the hoop and trim away excess stabilizer about 1/4"-1/2" from the stitching.

Step 3 - Rinse

Rinse remaining stabilizer out in warm running water. For stiffer lace and FSL structures, DO NOT rinse away all of the stabilizer. The lace should be just slightly tacky. For softer lace, rinse until all traces of the stabilizer are removed.

Step 4 - Dry

Lay right side down flat on a non-stick surface, such as a cooling rack, parchment paper or Teflon sheet. This minimizes the tendency for the lace to curl. Let the pieces dry completely before proceeding with any assembly.

Step 5 - Press

Once completely dry, press right side down on a OESD Perfect Embroidery Press Cloth.

Step 6 - Assemble Structure

Note: Specific assembly instructions for a design/collection may be found in the thread chart pdf following the individual design color charts.

Lace must be COMPLETELY DRY before assembly. Wetting the buttonettes or eyelets to assemble is not recommended and may result in them stretching and coming "unbuttoned" when dry.

Use a pair of OESD Alligator Clamps to insert the buttonettes into the eyelets. Insert the tip of the OESD Alligator Clamps into the eyelet, grasp the buttonette and pull through the eyelet. Alternatively, use a stiletto or tweezers to push the buttonette through the eyelet.

Helpful Tips

Limp Lace

If the design is not stiff enough, press the lace pieces on the wrong side while applying spray starch. After ironing, spray again with starch and allow to dry completely. This will stiffen the lace pieces nicely and aid in construction. Or easily re-stiffen by diluting some stabilizer scraps in water (or use liquid starch) and dipping the item in the solution. Lay flat to dry.

Eyelets Too Small

If any of the eyelets appear closed or too small to penetrate with Alligator Clamps, they may be stretched by inserting the small end of the OESD Perfect Point and Press Tool into the eyelet opening and stretching it open wide enough to accommodate the OESD Alligator Clamps.

Button Clips

During the assembly process, some structures pull on buttonettes that have already been inserted and could pull them out altogether. Putting a Button Clip on the assembled buttonette will keep it in position during the assembly process. Remove the Button Clips when the assembly is complete.


Alternative Construction Option

In some cases, the buttonettes may be pulled to the inside of a project, instead of being visible on the outside. Insert the OESD Alligator Clamps through the eyelet from the wrong, or inside, of the lace and grasp the corresponding buttonette. Pull the buttonette to the wrong side of the lace.

Pulling the buttonettes to the inside may cause stress on the ones already done. Button clips may be placed on the completed buttonette(s) to prevent them from pulling out of the eyelet during construction.


ATTENTION

When printing this document, any page scaling or page fitting options in your print dialog box must be turned OFF or set to NONE so that your files will print out at their actual size. Images not printed at actual size will not function as intended.



TO SAVE PAPER




Only print the desired image by navigating to the image's page, go to File > Print and select "Current page" in the print dialog box. Repeat for each desired image.



APPLIQUE PATTERNS





Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



APPLIQUE PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



APPLIQUE PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.




MIRRORED PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.




12467-01




12467-02



12467-03



12467-03



12467-04





12467-04

MIRRORED PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



MIRRORED PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.

