



**FREESTANDING
Diner**



1
Design

Fits hoop size 6" x 10" and larger

THREAD LIST



Isacord Thread Colors

0015 White (2 spools)

*** Project instructions included after design list.**

Note: One spool of 1000 meter thread is adequate for the project unless otherwise noted.

DESIGNS


Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

*Fabric Required

12686-01 Front Wall FSA

Size Inches:	Size mm:	Stitch Count:
3.03 X 7.37 in.	76.96 X 187.2 mm	45,487 St.

- 1. Placement Stitch 0015
- 2. Cut Line & Tackdown..... 0015
- 3. Lace..... 0015




Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

***Fabric Required**

12686-02 Front Door FSA

Size Inches: Size mm: Stitch Count:
3.65 X 3.03 in. 92.71 X 76.96 mm 24,079 St.



- 1. Placement Stitch 0015
- 2. Cut Line & Tackdown..... 0015
- 3. Lace..... 0015

***Fabric Required**

12686-03 Side Wall 1 FSA

Size Inches: Size mm: Stitch Count:
3.61 X 3.03 in. 91.69 X 76.96 mm 24,007 St.



- 1. Placement Stitch 0015
- 2. Cut Line & Tackdown..... 0015
- 3. Lace..... 0015

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

***Fabric Required**

12686-04 Side Wall 2 FSA

Size Inches: Size mm: Stitch Count:
3.61 X 3.03 in. 91.69 X 76.96 mm 24,007 St.

- 1. Placement Stitch 0015
- 2. Cut Line & Tackdown..... 0015
- 3. Lace..... 0015




***Fabric Required**

12686-05 Back Wall FSA

Size Inches: Size mm: Stitch Count:
3.03 X 7.38 in. 76.96 X 187.45 mm 46,387 St.

- 1. Placement Stitch 0015
- 2. Cut Line & Tackdown..... 0015
- 3. Lace..... 0015




Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

***Fabric Required**

12686-06 Inner Wall FSA

Size Inches: Size mm: Stitch Count:
3.09 X 7.37 in. 78.49 X 187.2 mm 26,268 St.


- 1. Placement Stitch 0015
- 2. Cut Line & Tackdown..... 0015
- 3. Lace..... 0015



12686-07 Roof FSL

Size Inches: Size mm: Stitch Count:
4.87 X 8 in. 123.7 X 203.2 mm 67,427 St.

- 1. Single Color Design..... 0015



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

***Fabric Required**

12686-08 Roof Arch Front FSA

Size Inches: Size mm: Stitch Count:
2.06 X 6.62 in. 52.32 X 168.15 mm 17,630 St.

- 1. Placement Stitch 0015
- 2. Cut Line & Tackdown..... 0015
- 3. Lace..... 0015
- 4. Lettering 0015



12686-09 Roof Arch Back FSL


Size Inches: Size mm: Stitch Count:
1.34 X 6.64 in. 34.04 X 168.66 mm 20,689 St.

- 1. Single Color Design..... 0015



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

***Fabric Required**




12686-10 Roof Top Snow FSA

Size Inches: Size mm: Stitch Count:
3.14 X 7.84 in. 79.76 X 199.14 mm 30,560 St.

- 1. Roof Placement Stitch..... 0015
- 2. Roof Cut Line & Tackdown 0015
- 3. Snow Placement Stitch 0015
- 4. Snow Cut Line & Tackdown..... 0015
- 5. Lace..... 0015

***Fabric Required**



12686-11 Roof Top FSA

Size Inches: Size mm: Stitch Count:
3.14 X 7.84 in. 79.76 X 199.14 mm 39,572 St.

- 1. Placement Stitch 0015
- 2. Cut Line & Tackdown..... 0015
- 3. Lace..... 0015


Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

***Fabric Required**

12686-12 Foundation FSA

Size Inches: Size mm: Stitch Count:
4.44 X 7.38 in. 112.78 X 187.45 mm 20,706 St.

- 1. Placement Stitch 0015
- 2. Cut Line & Tackdown..... 0015
- 3. Lace..... 0015



Stabilizers

- OESD AquaMesh WashAway
- OESD BadgeMaster WashAway
- OESD StabilStick CutAway

Fabrics/Textiles

- White cotton fabric 1/4 yard
- Note: Fabric sizes are estimates and may result in overage.

Notions & Tools

- OESD Alligator Clamps
- OESD Button Clips
- OESD Expert Embroidery Tape WashAway
- OESD Perfect Embroidery Press Cloth
- OESD Perfect Point and Press Tool
- Embroidery Needle Sharp 75/11

Isacord Thread Colors


- Per thread chart
- Match bobbin thread to top thread
- 0015 White (2 spools)

SUMMARY




Completed Size: 5 3/4" H x 7 3/4" W x 4" D

12686-01




Requires 1 Design

12686-02




Requires 1 Design

12686-03




Requires 1 Design

12686-04




Requires 1 Design

12686-05




Requires 1 Design

12686-06




Requires 1 Design

12686-07




Requires 1 Design

12686-08




Requires 1 Design

12686-09




Requires 1 Design

12686-10




or

12686-11



Requires 1 Design

12686-12



Requires 1 Design

Notes

The freestanding applique instructions, included in the collection, are general instructions. For demonstration purposes, a sample design that best demonstrates the technique is shown. Fabric and thread requirements will vary by design, but the general technique is the same.

All designs are stitched with matching thread in the top and bobbin.

For other designs in the collection, use the applique templates as a guide to the dimensions of the various applique pieces.

Note: Some thread colors in instructions have been changed or digitally enhanced for better visibility.

STEP 1

- Hoop one layer of OESD AquaMesh and one layer of OESD BadgeMaster for all designs.




STEP 2

- Adhere two layers of StabilStick CutAway to the wrong side of all applique fabrics to provide stiffness to the finished structure.
- Cut the prepared applique fabrics 1/4" - 1/2" larger than the templates.



STEP 3

- Load selected design into the machine.
- Example design is Front Wall FSA (12686-01).
- Thread the machine per the thread chart.
- Place hoop on the machine.
- Stitch Machine Step 1, Placement Stitch.




STEP 4

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Cut a piece of prepared fabric slightly larger than the placement line.
- Cover the placement line completely with the prepared fabric.
- Tape in place to secure.



STEP 5

- Return the hoop to the machine.
- Stitch Machine Step 2, Cut Line and Tackdown.



EMBROIDERY




STEP 6

- Remove the hoop from the machine, but NOT the project from the hoop.
- Trim the excess fabric as close to the cut line as possible.
- Return the hoop to the machine.
- Note: If the outermost row of stitching (cut line) is accidentally cut, the inner stitches (tackdown) will hold the applique in place.
- Tip: If the OESD AquaMesh is cut or a hole is created while trimming the fabric, use OESD Expert Embroidery Tape WashAway as a patch.



STEP 7

- Stitch Machine Step 3, Lace.
- Return the hoop to the machine and stitch the remaining steps according to the thread chart.
- When design is complete, remove the project from the hoop and trim the stabilizer 1/4" - 1/2" outside the design.
- NOTE: Stitch all required designs. Designs 12686-07 and 12686-09 are lace only, fabric not required.



ASSEMBLY




STEP 8

- Rinse each piece in warm running water until the design is only slightly sticky.
- Lay face down on a non-stick surface to dry. Parchment paper or a cooling rack work well. This prevents the piece from curling.
- Press each piece, right side down, on a Perfect Embroidery Press Cloth.



STEP 9

- Attach Front Wall FSA (12686-01) to Side Wall 1 FSA (12686-03) by pulling the three buttonettes along the right side of the Front Wall into the three eyelets along the left side of the Side Wall 1.




ASSEMBLY




STEP 10

- Attach Side Wall 2 FSA (12686-04) to the front wall by pulling the three buttonettes along the left side of the front wall into the three eyelets along the left side of Side Wall 2.



STEP 11

- Attach Front Door FSA (12686-02) to the front wall by pulling the six buttonettes of the front door into the six eyelets on the front wall.




ASSEMBLY




STEP 12

- Attach Back Wall FSA (12686-05) to the side walls 1 and 2 by pulling the three buttonettes on each side of the back wall into the three eyelets each of the side wall 1 and side wall 2.




STEP 13

- Attach Roof Arch Front FSA (12686-08) to Roof Top Snow FSA (12686-10) OR Roof Top FSA (12686-11) by pulling the six buttonettes on the roof into the six eyelets on the roof arch front.




STEP 14

- Attach Roof Arch Back FSA (12686-09) to the roof top by pulling the five buttonettes of the roof top along the back of roof top into the five eyelets of the roof arch back.



STEP 15

- Attach Inner Wall FSA (12686-06) to Roof FSL (12686-07) by pulling two buttonettes of inner wall into two eyelets of roof located around circle on roof.



STEP 16

- Attach the arch roof assembly to the roof by pulling the nine buttonettes of the arch assembly into the nine eyelets located in towards the center of the roof.



STEP 17

- Attach the two buttonettes on each side of the inner wall to the two eyelets on each of the side wall 1 and side wall 2.



ASSEMBLY




STEP 18

- Attach arch roof assembly to side walls by pulling the twelve buttonettes on walls into the twelve eyelets on roof.



STEP 19

- Attach Foundation FSA (12686-12) to the structure by pulling two buttonettes of inner wall into the two eyelets of foundation located in center.




ASSEMBLY



STEP 20

- Attach remaining six buttonettes of foundation into the six remaining eyelets of walls.



ASSEMBLY



FINISHING TOUCHES

- The Diner is complete. Enjoy.
- Add tea lights or pixie lights to create a glow.



Stabilizer

- OESD AquaMesh
- OESD BadgeMaster

Notions/Tools

- 80/12 Embroidery Ballpoint Titanium needle for extended needle life
- OESD Alligator Clamps
- OESD Button Clips
- OESD Perfect Point and Press Tool

Isacord Thread Colors

- All OESD designs are digitized with Isacord 40 wt. polyester thread as the top thread and in the bobbin.
- Refer to the thread chart for color specifications.
- Match bobbin thread color to the top thread.

Instructions

Step 1 - Hoop

For FSL structures, hoop one layer of OESD AquaMesh and one layer of OESD BadgeMaster. BadgeMaster contains more starch so, combined with the AquaMesh, the lace is more rigid. For other FSL, where a softer lace is desired, hoop two layers of AquaMesh.

Step 2 - Embroider

Stitch the design per the thread chart with matching thread in the bobbin at each color change. When complete, remove from the hoop and trim away excess stabilizer about 1/4"-1/2" from the stitching.

Step 3 - Rinse

Rinse remaining stabilizer out in warm running water. For stiffer lace and FSL structures, DO NOT rinse away all of the stabilizer. The lace should be just slightly tacky. For softer lace, rinse until all traces of the stabilizer are removed.

Step 4 - Dry

Lay right side down flat on a non-stick surface, such as a cooling rack, parchment paper or Teflon sheet. This minimizes the tendency for the lace to curl. Let the pieces dry completely before proceeding with any assembly.

Step 5 - Press

Once completely dry, press right side down on a OESD Perfect Embroidery Press Cloth.

Step 6 - Assemble Structure

Note: Specific assembly instructions for a design/collection may be found in the thread chart pdf following the individual design color charts.

Lace must be COMPLETELY DRY before assembly. Wetting the buttonettes or eyelets to assemble is not recommended and may result in them stretching and coming "unbuttoned" when dry.

Use a pair of OESD Alligator Clamps to insert the buttonettes into the eyelets. Insert the tip of the OESD Alligator Clamps into the eyelet, grasp the buttonette and pull through the eyelet. Alternatively, use a stiletto or tweezers to push the buttonette through the eyelet.

Helpful Tips

Limp Lace

If the design is not stiff enough, press the lace pieces on the wrong side while applying spray starch. After ironing, spray again with starch and allow to dry completely. This will stiffen the lace pieces nicely and aid in construction. Or easily re-stiffen by diluting some stabilizer scraps in water (or use liquid starch) and dipping the item in the solution. Lay flat to dry.

Eyelets Too Small

If any of the eyelets appear closed or too small to penetrate with Alligator Clamps, they may be stretched by inserting the small end of the OESD Perfect Point and Press Tool into the eyelet opening and stretching it open wide enough to accommodate the OESD Alligator Clamps.

Button Clips

During the assembly process, some structures pull on buttonettes that have already been inserted and could pull them out altogether. Putting a Button Clip on the assembled buttonette will keep it in position during the assembly process. Remove the Button Clips when the assembly is complete.


Alternative Construction Option

In some cases, the buttonettes may be pulled to the inside of a project, instead of being visible on the outside. Insert the OESD Alligator Clamps through the eyelet from the wrong, or inside, of the lace and grasp the corresponding buttonette. Pull the buttonette to the wrong side of the lace.

Pulling the buttonettes to the inside may cause stress on the ones already done. Button clips may be placed on the completed buttonette(s) to prevent them from pulling out of the eyelet during construction.


ATTENTION

When printing this document, any page scaling or page fitting options in your print dialog box must be turned OFF or set to NONE so that your files will print out at their actual size. Images not printed at actual size will not function as intended.



TO SAVE PAPER



Only print the desired image by navigating to the image's page, go to File > Print and select "Current page" in the print dialog box. Repeat for each desired image.



APPLIQUE PATTERNS





Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



APPLIQUE PATTERNS







Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



APPLIQUE PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.




APPLIQUE PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.

12686-11



12686-12



MIRRORED PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.




MIRRORED PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



12686-05



12686-06





12686-08

MIRRORED PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



MIRRORED PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.

