

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



**12739-01 Peace FSL**  
4.96 X 5.81 in.  
125.98 X 147.57 mm  
46,031 St.



**12739-02 Hope FSL**  
4.77 X 4.94 in.  
121.16 X 125.48 mm  
33,026 St.



**12739-03 Joy FSL**  
4.77 X 5.38 in.  
121.16 X 136.65 mm  
33,975 St.

Listings below indicate color sample, stitching order and suggested thread color number. Most numbers indicate Isacord thread.

Colors beginning with 7 refer to Yenmet Metallic and 9 refer to Isacord Multicolor Variegated.

**12739-01 Peace FSL**

1. Single Color Design .....0015

**12739-02 Hope FSL**

1. Single Color Design .....0015

**12739-03 Joy FSL**

1. Single Color Design .....0015

## General Freestanding Lace Guidelines

### Supplies:

#### Embroidery Thread:

- Use the same embroidery thread in the bobbin as the needle.

#### Needles:

- Use an Organ 80/12 Titanium needle for extended needle life.

#### Stabilizer:

- Use OESD AquaMesh stabilizer.

### Handy Hints:

#### For Stiffer Lace:

- DO NOT rinse away all of the stabilizer for a “stiffer” lace. Note that the thread may appear a shade darker if stabilizer is not removed completely.
- If you happen to wash too much out, easily re-stiffen by diluting some stabilizer scraps in water and dipping the item in the solution.

#### For Very Soft Lace:

- Cut away excess stabilizer. Remove remaining stabilizer by rinsing under warm running water until all traces of the stabilizer are gone. **NOTE:** If lace should become too limp to work with, dissolve stabilizer scraps in warm water and apply to the lace.

#### Drying Lace:

- The lace looks best when left to dry completely. Lay lace piece with right side down to dry. This will minimize the tendency for the lace to curl. Be sure to flatten the piece out entirely and allow ample time to dry.

### General Instructions

1. Hoop two layers of OESD AquaMesh Stabilizer.
2. Attach the hoop to the machine and select the design of your choice.
3. Stitch the design.
4. Remove the hoop from the machine and the design from the hoop. Trim excess stabilizer from the design.
5. Rinse away remaining stabilizer and allow it to dry.