

FREESTANDING HALLOWEEN LITTLE LANTERNS



4

Designs

Fits hoop sizes 8" x 12" and larger

THREAD LIST



Isacord Thread Colors

- 0015 White
- 0020 Black
- 0506 Yellow Bird
- 1010 Toast
- 2830 Wild Iris


*** Project instructions included after design list.**

Note: One spool of 1000 meter thread is adequate for the project unless otherwise noted.

DESIGNS

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

*Fabric Required




12886-01 Spider Web Lantern FSA

Size Inches:	Size mm:	Stitch Count:
5.30 X 2.97 in.	134.6 X 75.5 mm	14411 St.

- 1. Orange Fabric Placement Stitch 0020
- 2. Cut Line and Tackdown 0020
- 3. Black Inner Detail 0020
- 4. Black Cover Stitch and Lace 0020

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.


12886-02 Spider Web Lantern FSL



Size Inches: Size mm: Stitch Count:
5.31 X 2.97 in. 134.8 X 75.5 mm 26835 St.

- 1. Orange Lace..... 1010
- 2. Black Inner Lace..... 0020
- 3. Black Outer Lace..... 0020

12886-03 Spider Web Lantern Base FSL



Size Inches: Size mm: Stitch Count:
2.52 X 2.52 in. 64.1 X 64.1 mm 9504 St.

- 1. Single Color Design..... 0020

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.


***Fabric Required**



12886-04 Bat Lantern FSA

Size Inches: Size mm: Stitch Count:
6.56 X 2.97 in. 166.6 X 75.5 mm 22992 St.

- 1. Black Fabric Placement Stitch..... 1010
- 2. Cut Line and Tackdown 1010
- 3. Orange Fabric Placement Stitch 1010
- 4. Cut Line and Tackdown 1010
- 5. Purple Fabric Placement Stitch 1010
- 6. Cut Line and Tackdown 1010
- 7. Orange Detail and Cover Stitch..... 1010
- 8. Purple Detail and Cover Stitch 2830
- 9. Black Detail and Cover Stitch..... 0020



12886-05 Bat Lantern FSL

Size Inches: Size mm: Stitch Count:
6.56 X 2.97 in. 166.7 X 75.5 mm 34867 St.

- 1. Orange Lace..... 1010
- 2. Purple Lace 2830
- 3. Black Lace..... 0020

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

12886-06 Bat Lantern Base FSL




Size Inches: Size mm: Stitch Count:
2.52 X 2.52 in. **64.1 X 64.1 mm** **9504 St.**

■ 1. Single Color Design..... 2830

*Fabric Required

12886-07 Candy Corn Lantern FSA



Size Inches: Size mm: Stitch Count:
4.46 X 2.14 in. **113.2 X 54.4 mm** **11933 St.**


- 1. White Fabric Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. Orange Fabric Placement Stitch 0015
- 4. Cut Line and Tackdown 0015
- 5. Yellow Fabric Placement Stitch 0015
- 6. Cut Line and Tackdown 0015
- 7. White Detail and Cover Stitch 0015
- 8. Orange Detail and Cover Stitch..... 1010
- 9. Yellow Detail and Cover Stitch 0506

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

12886-08 Candy Corn Lantern FSL

Size Inches: Size mm: Stitch Count:
4.46 X 2.14 in. 113.2 X 54.4 mm 14719 St.

- 1. White Lace 0015
- 2. Orange Lace..... 1010
- 3. Yellow Lace 0506



12886-09 Candy Corn Lantern Base FSL


Size Inches: Size mm: Stitch Count:
2.93 X 3.39 in. 74.4 X 86.0 mm 11125 St.

- 1. Single Color Design..... 0506



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.


***Fabric Required**



12886-10 Gothic Lantern FSA

Size Inches: Size mm: Stitch Count:
7.10 X 2.14 in. 180.2 X 54.4 mm 17078 St.

- 1. Purple Fabric Placement Stitch 2830
- 2. Cut Line and Tackdown 2830
- 3. Purple Detail 2830
- 4. Black Inner Detail 0020
- 5. Black Outer Detail and Cover Stitch 0020



12886-11 Gothic Lantern FSL

Size Inches: Size mm: Stitch Count:
7.10 X 2.14 in. 180.3 X 54.4 mm 25577 St.


- 1. Purple Lace 2830
- 2. Black Lace 0020
- 3. Black Outer Lace 0020

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

12886-12 Gothic Lantern Base FSL

Size Inches:	Size mm:	Stitch Count:
2.93 X 3.39 in.	74.4 X 86.0 mm	11125 St.

■ 1. Single Color Design..... 0020



COLLECTION SUPPLIES



Stabilizers

- OESD AquaMesh WashAway
- OESD BadgeMaster WashAway
- OESD StabilStick CutAway
- OESD AquaMesh Plus WashAway

Fabrics/Textiles

- 1/8 yard for each freestanding applique lantern
- Note: Fabric sizes are estimates and may result in overage.

Notions & Tools

- OESD Alligator Clamps
- OESD Button Clips
- Expert Embroidery Tape WashAway
- Expert Punch Tool
- OESD Perfect Embroidery Press Cloth
- Embroidery Needle Ballpoint 75/11

Isacord Thread Colors

- Per the thread chart
- All designs are stitched with matching thread, top and bobbin.

SUMMARY



5 1/2" tall




12886-01




Requires 2 designs

12886-02



Requires 2 designs

12886-03




Requires 1 Base design



6 1/2" tall




12886-04




Requires 2 designs

12886-05



Requires 2 designs

12886-06



Requires 1 Base design



SUMMARY



4 1/2" tall



12886-07




Requires 3 designs

12886-08



Requires 3 designs

12886-09




Requires 1 Base design



7 1/4" tall




12886-10




Requires 3 designs

12886-11



Requires 3 designs

12886-12



Requires 1 Base design




NOTES

- The freestanding applique instructions, included in the collection, are general instructions. For demonstration purposes, a sample design that best demonstrates the technique is shown. Fabric and thread requirements will vary by design, but the general technique is the same.
- All designs are stitched with matching thread in the top and bobbin.
- Note: Some thread colors in instructions have been changed or digitally enhanced for better visibility.


STEP 1

- Hoop one layer of AquaMesh and one layer BadgeMaster for all designs.



STEP 2

- Adhere two layers of StabilStick CutAway to the wrong side of all applique fabrics to provide stiffness to the finished structure.




EMBROIDERY



STEP 3

- Load selected design into the machine.
- Example design is 12886-01
- Thread the machine per the thread chart.
- Place hoop on the machine.
- Stitch Machine Step 1, Orange Fabric Placement Stitch.




STEP 4

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Place the prepared applique fabric, right side up, completely covering the placement stitch.
- Tape in place to secure.



STEP 5

- Return the hoop to the machine.
- Stitch Machine Step 2, Cut Line and Tackdown.




EMBROIDERY



STEP 6

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Trim the excess fabric as close to the cut line stitching as possible.
- If the outermost stitches (cut line) are cut, the inner stitches (tackdown) will still hold the applique in place.
- Tip: If the AquaMesh is cut or a hole is created while trimming the fabric, use OESD Expert Embroidery Tape WashAway.



STEP 7

- Return the hoop to the machine and stitch the remaining machine steps per the thread chart.
- Remember to match the bobbin thread to the upper thread.



STEP 8

- When the design is complete, remove the project from the hoop and trim the stabilizer 1/4"- 1/2" outside the design.



ASSEMBLY



STEP 9

- Rinse each piece in warm running water until the design is only slightly tacky.
- Place right side down on a non-stick surface to dry. Parchment paper or a cooling rack work well to prevent curling. Dry completely.
- Once dry, press right side down on a Perfect Embroidery Press Cloth.



STEP 10

- Use OESD Punch Tool with the appropriate attachment to create the eyelets indicated in the punch tool guide.
- Note: Punch tool guides are on page 18.



STEP 11

- Arrange the side pieces alternating Square Lantern 1 FSA (12886-01) and Square Lantern 1 FSL (12886-02) around Square Lantern Base FSL (12886-03) as shown.



ASSEMBLY



STEP 12

- Thread the sewing machine with matching thread in the top and bobbin.
- Stitch the base and the 4 sides together using a multi-step zigzag stitch (also known as a serpentine stitch).
- Back stitch at the beginning and end to secure.
- Trim thread tails.
- Tip: An open toe or edge stitch foot is helpful.
- Fold and press to shape.



STEP 13

- Match the eyelets and buttonettes.
- Pull each buttonette through the corresponding eyelet, using button clips to temporarily hold them in place, as needed.



FINISHING TOUCHES

- Add tea lights or pixie lights to create a glow.



General Freestanding Lace Guide



Stabilizer

- OESD AquaMesh
- OESD BadgeMaster

Notions/Tools

- 80/12 Embroidery Ballpoint Titanium needle for extended needle life
- OESD Alligator Clamps
- OESD Button Clips
- OESD Perfect Point and Press Tool

Isacord Thread Colors

- All OESD designs are digitized with Isacord 40 wt. polyester thread as the top thread and in the bobbin.
- Refer to the thread chart for color specifications.
- Match bobbin thread color to the top thread.

Instructions

Step 1 - Hoop

For FSL structures, hoop one layer of OESD AquaMesh and one layer of OESD BadgeMaster. BadgeMaster contains more starch so, combined with the AquaMesh, the lace is more rigid. For other FSL, where a softer lace is desired, hoop two layers of AquaMesh.

Step 2 - Embroider

Stitch the design per the thread chart with matching thread in the bobbin at each color change. When complete, remove from the hoop and trim away excess stabilizer about 1/4"-1/2" from the stitching.

Step 3 - Rinse

Rinse remaining stabilizer out in warm running water. For stiffer lace and FSL structures, DO NOT rinse away all of the stabilizer. The lace should be just slightly tacky. For softer lace, rinse until all traces of the stabilizer is removed.

Step 4 - Dry

Lay right side down flat on a non-stick surface, such as a cookie rack, parchment paper or Teflon sheet. This minimizes the tendency for the lace to curl. Let the pieces dry completely before proceeding with any assembly.

Step 5 - Press

Once completely dry, press right side down on a OESD Perfect Embroidery Press Cloth.

Step 6 - Assemble Structure

Note: Specific assembly instructions for a design/collection may be found in the thread chart pdf following the individual design color charts.

Lace must be COMPLETELY DRY before assembly. Wetting the buttonettes or eyelets to assemble is not recommended and may result in them stretching and coming "unbuttoned" when dry.

Use a pair of OESD Alligator Clamps to insert the buttonettes into the eyelets. Insert the tip of the OESD Alligator Clamps into the eyelet, grasp the buttonette and pull through the eyelet. Alternatively, use a stiletto or tweezers to push the buttonette through the eyelet.

Helpful Tips

Limp Lace

If the design is not stiff enough, press the lace pieces on the wrong side while applying spray starch. After ironing, spray again with starch and allow to dry completely. This will stiffen the lace pieces nicely and aid in construction. Or easily re-stiffen by diluting some stabilizer scraps in water (or use liquid starch) and dipping the item in the solution. Lay flat to dry.

Eyelets Too Small

If any of the eyelets appear closed or too small to penetrate with Alligator Clamps, they may be stretched by inserting the small end of the OESD Perfect Point and Press Tool into the eyelet opening and stretching it open wide enough to accommodate the OESD Alligator Clamps.

Button Clips

During the assembly process, some structures pull on buttonettes that have already been inserted and could pull them out altogether. Putting a Button Clip on the assembled buttonette will keep it in position during the assembly process. Remove the Button Clips when the assembly is complete.

Alternative Construction Option

In some cases, the buttonettes may be pulled to the inside of a project, instead of being visible on the outside. Insert the OESD Alligator Clamps through the eyelet from the wrong, or inside, of the lace and grasp the corresponding buttonette. Pull the buttonette to the wrong side of the lace.

Pulling the buttonettes to the inside may cause stress on the ones already done. Button clips may be placed on the completed buttonette(s) to prevent them from pulling out of the eyelet.


12886-01




12886-04



12886-07




12886-10



-  = 2 MM
-  = 3 MM
-  = 4 MM


ATTENTION

When printing this document, any page scaling or page fitting options in your print dialog box must be turned OFF or set to NONE so that your files will print out at their actual size. Images not printed at actual size will not function as intended.



TO SAVE PAPER





Only print the desired image by navigating to the image's page, go to File > Print and select "Current page" in the print dialog box. Repeat for each desired image.



APPLIQUE PATTERNS





Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



APPLIQUE PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.




MIRRORED PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.




12886-01



12886-04



12886-04




12886-04

MIRRORED PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.




12886-07



12886-07



12886-07



12886-10