


Cutwork Crosses



Collection No. 12965
15 Designs

MATERIALS



Isacord Thread Colors

- 3951 Azure Blue
- 3963 Hint of Blue
- 5650 Spring Frost
- 6051 Jalapeno

Note: One spool of 1000 meter thread is adequate for the project unless otherwise noted.



MATERIALS



Stabilizers

- OESD AquaMesh Plus WashAway

Fabrics/Textiles

- Start Here by OESD Tea Towel White
- Napkins

Notion & Tools

- OESD Grippy GRID
- OESD Perfect Scoring Tool
- OESD Expert Embroidery Tape WashAway
- OESD Perfect Embroidery Press Cloth
- Embroidery Needle Ballpoint 80/12

Isacord Thread Colors

- Per the thread chart
- Match bobbin thread to top thread



SUMMARY



12965-01

Requires 1 Design




12965-02

Requires 1 Design



12965-03

Requires 1 Design



12965-04

Requires 1 Design



12965-05

Requires 1 Design



12965-06

Requires 1 Design




12965-07

Requires 1 Design




12965-08

Requires 1 Design




12965-09

Requires 1 Design



12965-10

Requires 1 Design




12965-11

Requires 1 Design




12965-12

Requires 1 Design




12965-13

Requires 1 Design



12965-14

Requires 1 Design



12965-15

Requires 1 Design

General Instructions

The cutwork instructions included in the collection are general instructions. For demonstration purposes, a sample design that best demonstrates the technique is shown. Fabric and thread requirements will vary by design, but the general technique is the same.

Note: Some thread colors in instructions have been changed or digitally enhanced for better visibility.


Step 1

- Hoop one layer of AquaMesh Plus with the paper (shiny side up).
- Use the OESD Perfect Scoring Tool to score the paper.
- Remove the paper to reveal the adhesive surface.




Step 2

- Fold the towel in half lengthwise, right sides together.
- Position the towel on the hooped stabilizer with the vertical fold aligned with the vertical center markings on the hoop.
- Finger press to secure.
- Unfold the towel.
- Finger press to secure.



□ Step 3

- Load selected design into the machine.
- Example design is 12965-01.
- Thread the machine per the thread chart.
- Place the hoop on the machine.
- Stitch Machine Step 1, Cut Line.



□ Step 4

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Carefully trim the fabric inside the Cut Line stitching.
Tip: If the stabilizer is cut or a hole is created while trimming the fabric, use Expert Embroidery Tape WashAway as a patch.



□ Step 5

- Return the hoop to the machine.
- Stitch the remaining machine steps, per the thread chart.
- Match the bobbin thread to the upper thread.



EMBROIDERY

□ Step 6

- When the design is complete, remove the project from the hoop and trim the stabilizer 1/4" - 1/2" outside the design.
- Rinse in warm running water to remove the remaining AquaMesh Plus.
- Place right side down on a non-stick surface to dry. Using parchment paper or a cooling rack work well to prevent curling. Dry completely.
- Once dry, press right side down on a Perfect Embroidery Press Cloth.



□ Step 7

- The project is complete. Enjoy!



General Instructions

The instructions included in the collection, are general instructions. For demonstration purposes, a sample design that best demonstrates the technique is shown. Fabric and thread requirements will vary by design, but the general technique is the same.

Note: Some thread colors in instructions have been changed or digitally enhanced for better visibility.

Example uses #PK10017-02.

Step 8

- Hoop one layer of AquaMesh Plus with the paper (shiny) side up.
- Score and remove paper to reveal the adhesive surface.



Step 9

- Stitch Machine Step 1, Corner Placement Stitch.



□ Step 10

- Place the napkin so the edges of one corner align with the placement line.



□ Step 11

- Stitch Machine Step 2, Cut Line and Tackdown.



□ Step 12

- Trim the excess fabric as close to the cut line as possible. If the outermost stitches (cut line) are cut, the inner stitches (tackdown) will hold the napkin in place.

IMPORTANT: Be sure to trim on the side that will cut away the corner and leave the body intact.

Tip: If the stabilizer is cut or a hole is created while trimming the fabric, use Expert Embroidery Tape WashAway as a patch.



□ Step 13

- Stitch the remaining machine steps, per thread chart.
- Match the bobbin thread to the upper thread.



□ Step 14

- When the design is complete, remove the project from the hoop and trim the stabilizer 1/4" - 1/2" outside the design.



□ Step 15

- Rinse in warm running water to remove the remaining AquaMesh Plus.
- Place right side down on a non-stick surface to dry. Parchment paper or a cooling rack will prevent curling. Dry completely.
- Once dry, press right side down on a Perfect Embroidery Press Cloth.
- ENJOY!



GENERAL FREESTANDING LACE GUIDE

OESD™ PREMIER
COLLECTION



Stabilizer

- OESD AquaMesh
- OESD BadgeMaster

Notion/Tools

- 80/12 Embroidery Ballpoint Titanium needle for extended needle life
- OESD Alligator Clamps
- OESD Button Clips
- OESD Perfect Point and Press Tool

Isacord Thread Colors

- All OESD designs are digitized with Isacord 40 wt. polyester thread as the top thread and in the bobbin.
- Refer to the thread chart for color specifications.
- Match bobbin thread color to the top thread.

Instructions

Step 1 - Hoop

For FSL structures, hoop one layer of OESD AquaMesh and one layer of OESD BadgeMaster. BadgeMaster contains more starch so, combined with the AquaMesh, the lace is more rigid.

For other FSL, where a softer lace is desired, hoop two layers of AquaMesh.

Step 2 - Embroider

Stitch the design per the thread chart with matching thread in the bobbin at each color change.

When complete, remove from the hoop and trim away excess stabilizer about 1/4"-1/2" from the stitching.

Step 3 - Rinse

Rinse remaining stabilizer out in warm running water.

For stiffer lace and FSL structures, DO NOT rinse away all of the stabilizer. The lace should be just slightly tacky.

For softer lace, rinse until all traces of the stabilizer is removed.

Step 4 - Dry

Lay right side down flat on a non-stick surface, such as a cookie rack, parchment paper or Teflon sheet. This minimizes the tendency for the lace to curl.

Let the pieces dry completely before proceeding with any assembly.

Step 5 - Press

Once completely dry, press right side down on a OESD Perfect Embroidery Press Cloth.

Step 6 - Assemble Structure

Note: Specific assembly instructions for a design/collection may be found in the thread chart pdf following the individual design color charts.

Lace must be COMPLETELY DRY before assembly. Wetting the buttonettes or eyelets to assemble is not recommended and may result in them stretching and coming "unbuttoned" when dry.

Use a pair of OESD Alligator Clamps to insert the buttonettes into the eyelets. Insert the tip of the OESD Alligator Clamps into the eyelet, grasp the buttonette and pull through the eyelet. Alternatively, use a stiletto or tweezers to push the buttonette through the eyelet.

Helpful Tips

Limp Lace

If the design is not stiff enough, press the lace pieces on the wrong side while applying spray starch. After ironing, spray again with starch and allow to dry completely. This will stiffen the lace pieces nicely and aid in construction. Or easily re-stiffen by diluting some stabilizer scraps in water (or use liquid starch) and dipping the item in the solution. Lay flat to dry.

Eyelets Too Small

If any of the eyelets appear closed or too small to penetrate with Alligator Clamps, they may be stretched by inserting the small end of the OESD Perfect Point and Press Tool into the eyelet opening and stretching it open wide enough to accommodate the OESD Alligator Clamps.

Button Clips

During the assembly process, some structures pull on buttonettes that have already been inserted and could pull them out altogether. Putting a Button Clip on the assembled buttonette will keep it in position during the assembly process. Remove the Button Clips when the assembly is complete.

Alternative Construction Option


In some cases, the buttonettes may be pulled to the inside of a project, instead of being visible on the outside.

Insert the OESD Alligator Clamps through the eyelet from the wrong, or inside, of the lace and grasp the corresponding buttonette. Pull the buttonette to the wrong side of the lace.


Pulling the buttonettes to the inside may cause stress on the ones already done. Button clips may be placed on the completed buttonette(s) to prevent them from pulling out of the eyelet.

PUNCH TOOL GUIDES

12965-01



12965-02




12965-03




12965-05



12965-06



12965-07



● = 2 MM

● = 3 MM

● = 4 MM

CUT OUT




PUNCH TOOL GUIDES

OESD™ PREMIER COLLECTION




12965-08




12965-09




12965-10



12965-14



12965-15



● = 2 MM

● = 3 MM

● = 4 MM

CUT OUT

