

#51257 3 DESIGNS



FREESTANDING CANDY COTTAGE

MATERIALS



Isacord Thread Colors

0015 White (2 spools)

1133 Peru

1753 Strawberries N' Cream

2155 Pink Tulip

4430 Island Waters

5440 Mint

* Project instructions included after design list.

Note: One spool of 1000 meter thread is adequate for the project unless otherwise noted.

FABRIC REQUIRED



51257-01 Front Wall FSA

Size Inches:	Siz	e mm:	Stitch Count:
5.99 X 4.62 in.	152.2 X	117.2 mm	27376 St.
1. Brown Fabr	ric Placeme	ent Stitch	0015
2. Cut Line an	d Tackdow	'n	0015
3. Green Fabr	ic Placeme	ent Stitch	0015
4. Cut Line an	d Tackdow	n	0015
5. White Lace	Fill		0015
6. Tan Detail .			1133
7. Pink Lace			1753
8. Green Lace	and Detai	l	5440
9. Light Pink L	ace and D	etail	2155
10. Light Blue [Detail		4430
11. White Deta	il		0015
12. White Lace	and Detail		0015



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

FABRIC REQUIRED



51257-02 Left Wall FSA

Size Inches:	Size	mm:	Stitch Count:
3.00 X 4.06 in.	76.2 X 1	03.1 mm	21421 St.
1. Brown Fabric			
3. White Lace F			
4. White Detail			0015
5. Light Pink La	ace and De	tail	2155
6. Pink Lace ar	nd Detail		1753
7. Green Lace	and Detail.		5440
8. Light Pink Ca	andy Cane		2155
9. Light Blue D	etail		4430
10. White Detail			0015
11. White Lace a	and Detail		0015



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

FABRIC REQUIRED




51257-03 Back Wall FSA

Size Inches:	Size	e mm:	Stitch Count:
6.06 X 4.75 in.	154.0 X	120.7 mm	28522 St.
1. Brown Fabr	ic Placeme	nt Stitch	0015
2. Cut Line an	d Tackdow	n	0015
3. Green Fabr	ic Placeme	nt Stitch	0015
4. Cut Line an	d Tackdow	n	0015
5. White Lace	Fill		0015
6. Tan Detail			1133
7. Light Pink L	ace and De	etail	2155
8. Pink Lace a	nd Detail		1753
9. Light Blue D	etail		4430
10. Green Lace			
11. Pink Detail.			2155
12. Light Blue D	etail		4430
13. White Detai	l		0015
14. Pink Detail.			1753
15. White Detai	l		0015
16. White Lace	and Detail		0015



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.


FABRIC REQUIRED



51257-04 Inner Wall FSA

Size Inches:	Size mm:	Stitch Count:
3.00 X 4.30 in.	76.3 X 109.2 mm	20552 St.
1. Brown Fabr	ic Placement Stitch	0015
2. Cut Line and	d Tackdown	0015
3. Lace		0015
4. Pink Stripes	;	1753
	es	
-	1	

FABRIC REQUIRED




51257-05 Roof 1 FSA

Size Inches:	Size mm:	Stitch Count:
4.68 X 5.32 in. 118.9	X 135.0 mm	27078 St.
1. White Felt Placem	ent Stitch	0015
2. Cut Line and Tack	down	0015
3. White Lace Fill		0015
4. White Lace and D	etail	0015
5. Pink Dots		1753
6. Light Pink Dots		2155
7. Light Blue Dots		4430
8. Green Dots		5440



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

FABRIC REQUIRED



51257-06 Roof 2 FSA

Size Inches:	Size mm:	Stitch Count:
4.66 X 5.32 in. 118.4	X 135.2 mm	26585 St.
1. White Felt Placen	nent Stitch	0015
2. Cut Line and Tack	kdown	0015
3. White Lace Fill		0015
4. White Lace and D)etail	0015
5. Light Blue Dots		4430
6. Green Dots		5440
7. Pink Dots		1753
8. Light Pink Dots		2155

FABRIC REQUIRED




51257-07 Front Walls FSA

Size Inches:	Size mm:	Stitch Count:
7.73 X 5.02 in. 19	6.3 X 127.4 m	nm 47260 St.
1. Brown Fabric I	Placement Stitch.	0015
2. Cut Line and T	ackdown	0015
3. White Lace Fil	l	0015
4. Light Blue Det	ail	4430
5. Light Pink Det		
6. White Detail		
7. Green Detail		5440
8. Light Blue Det	ail	4430
9. Light Pink Det		
10. Pink Lace and	Detail	1753
11. Light Pink Det	ail	2155
12. White Detail		0015
13. Green Detail		5440
14. White Lace an	d Detail	0015



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.


FABRIC REQUIRED



51257-08 Roof 3 FSA

Size Inches:	Size mm:	Stitch Count:
6.32 X 4.24 in. 160	.4 X 107.8 mm	33998 St.
1. White Felt Place	ement Stitch	0015
2. Cut Line and Ta	ckdown	0015
3. White Lace Fill.		0015
4. White Lace and	Detail	0015
5. Pink Dots		1753
6. Green Dots		5440
7. Light Pink Dots		2155
8. Light Blue Dots		4430

FABRIC REQUIRED




51257-09 Chimney FSA

1. Brown Fabric Placement Stitch	ch Count: 502 St.
□ 2. Cut Line and Tackdown 00 □ 3. White Lace 00 ■ 4. Green Dot 54 ■ 5. Light Blue Dot 44 ■ 6. Light Pink Dot 21 ■ 7. Pink Dot 17 □ 8. White Detail 00 □ 9. White Lace and Detail 00	0015 5440 4430 2155 1753 0015




Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



51257-10 Icicles 1 FSL

Size Inches:	Size mm:	Stitch Count:
4.43 X 4.44 in. 1	12.6 X 112.7 mm	11621 St.
1. Bottom Lace	Fill	0015
2. Bottom Lace	and Detail	0015
3. Top Lace Fill		0015
4. Top Lace and	l Detail	0015

51257-11 Icicles 2 FSL




Size Inches:		Siz	e mm:	Stitch Count:
2.26 X 3.42 in.	57.3	X	86.9 mm	5144 St.
1. Lace Fill				0015
2. Lace and Do	etail			0015



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

FABRIC REQUIRED



51257-12 Foundation 1 FSA

Size Inches:	Size mm:	Stitch Count:
5.52 X 4.95 in. 14	0.2 X 125.8 mm	19288 St.
1. Brown Fabric I	Placement Stitch	1133
2. Cut Line and T	ackdown	1133
3. Tan Detail		1133
□ 4 White Lace		0015

FABRIC REQUIRED



51257-13 Foundation 2 FSA

Size Inches:	Size mm:		Stitch Count:
2.59 X 3.28 in.	65.8 X	83.2 mm	6127 St.
1. Brown Fabr	ic Placem	ent Stitch	1133
2. Cut Line and	d Tackdov	vn	1133
3. Tan Detail			1133
4 White Lace			0015



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.


FABRIC REQUIRED



51257-14 Tree Section 1 FSA

Size Inches:	Size mm:		Stitch Count:
5.53 X 3.75 in.	140.3 X	95.2 mm	17325 St.
1. Brown Fabr	ic Placeme	nt Stitch	0015
2. Cut Line an	d Tackdowr	١	0015
3. Snow Lace	Fill		0015
4. Tree Lace a	ind Detail		1133
5. Snow Lace.			0015

FABRIC REQUIRED



51257-15 Tree Section 2 FSA

Size Inches:	Siz	e mm:	Stitch Count:
5.46 X 3.77 in.	138.8 X	95.7 mm	17542 St.
1. Brown Fabri	c Placem	ent Stitch	0015
2. Cut Line and	d Tackdow	/n	0015
3. Snow Lace	Fill		0015
4. Tree Lace a	nd Detail.		1133
5 Snow Lace			0015



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



51257-16 Small Tree Section 1 FSL

Size Inches:	Siz	e mm:	Stitch Count:
4.53 X 3.07 in.	115.0 X	78.0 mm	25482 St.
1. Tree Lace F	Fill		1133
2. Snow Lace	Fill		0015
3. Tree Lace			1133
4. Snow Lace.			0015



51257-17 Small Tree Section 2 FSL

Size Inches:	Size mm:	Stitch Count:
4.45 X 3.07 in.	113.0 X 78.0 mm	25772 St.
1. Tree Lace F	ill	1133
2. Snow Lace	Fill	0015
3. Tree Lace		1133
☐ 4 Snow Lace		0015

MATERIALS



Stabilizers

- OESD AquaMesh WashAway
- OESD BadgeMaster WashAway
- OESD StabilStick CutAway

Fabrics/Textiles

- 1/4 yard tan cotton fabric
- 1 9" x 12" sheet white felt
- Note: Fabric sizes are estimates and may result in overage.

Notion & Tools

- OESD Alligator Clamps
- OESD Button Clips
- OESD Perfect Punch Tool
- OESD Perfect Embroidery Press Cloth
- Expert Embroidery Tape WashAway

Isacord Thread Colors

- Per thread chart
- For Cottage match bobbin thread to top thread on last color change only.
- For Trees match bobbin thread to top thread on all colors.

SUMMARY

Requires 1 Design

Requires 1 Design





Completed Size: 6.25" x 7.75" x 5.25"



Requires 1 Design It is a violation of Copyright law to make and distribute copies of electronic designs or artwork. Electronic designs are licensed to the original purchaser for use at one location. ©2021 OESD, LLC. All rights reserved.

SUMMARY





Completed Size: 4.5" x 3" x 3"



Completed Size: 5.5" x 3.75" x 3.75"



Requires 1 Design



Requires 1 Design



Requires 1 Design



Requires 1 Design



Notes

The freestanding applique instructions, included in the collection, are general instructions. For demonstration purposes, a sample design that best demonstrates the technique is shown. Fabric and thread requirements will vary by design, but the general technique is the same.

For Cottage - match bobbin thread to top thread on last color change only. For Trees - match bobbin thread to top thread on all colors.

Note: Some thread colors in instructions have been changed or digitally enhanced for better visibility.

Step 1

 Adhere two layers of StabilStick CutAway to the wrong side of all applique fabrics to provide stiffness to the finished structure.



Step 2

· Hoop one layer of AquaMesh and one layer of BadgeMaster for all designs.





Step 3

• Stitch Machine Step 1, Brown Fabric Placement Stitch.



Step 4

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Completely cover the placement stitch with the prepared fabric.
- Tape in place to secure.



Step 5

- · Return the hoop to the machine.
- Stitch Machine Step 2, Cut Line and Tackdown.





Step 6

- Remove the hoop from the machine, but NOT the project from the hoop.
- Trim the excess fabric as close to the cut line stitching as possible. If the
 outermost stitches are cut, the inner stitches will still hold the applique in
 place.
- Tip: If the AquaMesh is cut or a hole is created while trimming the fabric, use OESD Expert Embroidery Tape WashAway or AquaMesh Plus as a patch.



Step 7

- · Return the hoop to the machine.
- Stitch Machine Step 3, Green Fabric Placement Stitch.



Step 8

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Place the prepared applique fabric, right side up, completely covering the placement stitch.
- Tape in place to secure.





Step 9

- · Return the hoop to the machine.
- Stitch Machine Step 4, Cut Line and Tackdown.



Step 10

- Remove the hoop from the machine, but NOT the project from the hoop.
- Trim the excess fabric as close to the cut line stitching as possible.



Step 11

• Return the hoop to the machine and stitch the remaining colors according to the thread chart.





Step 12

• When design is complete, remove the project from the hoop and trim the stabilizer 1/4" - 1/2" outside the design.







Step 13

- Rinse each piece in warm running water until the design is only slightly sticky.
- Lay face down on a non-stick surface to dry. Parchment paper or a cooling rack work well. This prevents
 the piece from curling.
- When dry, press each piece, right side down, on a Perfect Embroidery Press Cloth.

Step 14

- Before assembly, use a utility knife and cut through all the layers of the tab entry. Take care to not cut the satin stitching.
- Use the Perfect Punch Tool with the 3mm attachment, to punch holes in the eyelets indicated in the cutting guidelines.





Step 15

- Line up the wall pieces, 51257-01, 51257-02, 51257-03 and 51257-04, to connect.
- · Thread the sewing machine with matching thread in the top and bobbin.
- An open toe or edge stitch foot is helpful.
- Stitch together using a multi-step zigzag stitch (also known as a serpentine stitch).
- Back stitch at the beginning and end to secure.
- Trim thread tails.
- Fold and press to shape.





Step 16

 Match the eyelets and buttonettes on walls 51257-O3 to 51257-O4. Pull each buttonette through the corresponding eyelet, using button clips to temporarily hold them in place, as needed.





Step 17


- Line up roof pieces 51257-05 and 51257-06 to connect.
- Load the sewing machine with matching thread in the top and bobbin.
- · Stitch together using a multi-step zigzag.
- Back stitch at the beginning and end to secure.
- Trim thread tails.





Step 18

• Match the roof eyelets to the buttonettes from 51257-10 lcicles. Pull each buttonette through the corresponding eyelet.





Step 19


Match the roof eyelets to the house buttonettes.
 Pull each buttonette through the corresponding eyelet.





Step 20

 Match the eyelets and buttonettes of the chimney 51257-09. Pull each buttonette through the corresponding eyelet.





Step 21

 Insert the chimney tabs into the corresponding roof tab entry points.









Step 22


 Match the roof eyelets to the wall buttonettes on 51257-07. Pull each buttonette through the corresponding eyelet.





Step 23

 Insert the tabs into the corresponding tab entry points.





Step 24

Match the house eyelets to the buttonettes on 51257-12. Pull each buttonette
through the corresponding eyelet, using button clips to temporarily hold them
in place, as needed.





Step 25

Match the house eyelets to the buttonettes on 51257-13. Pull each buttonette
through the corresponding eyelet, using button clips to temporarily hold them
in place, as needed.



Step 26

• Freestanding Candy Cottage is complete.





Step 1

Hoop one layer of OESD AquaMesh and one layer of OESD BadgeMaster.



Step 2

 Adhere two layers of StabilStick CutAway to the wrong side of all applique fabrics, to provide stiffness to the finished structure.



Step 3


- · Load selected design into the machine.
- Design in the example is 51257-14.
- Thread the machine per the thread chart.
- Stitch Machine Step 1, Brown Fabric Placement Stitch.
- Match the bobbin thread to the upper thread for all colors.





Step 4

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Completely cover the placement stitch with the prepared fabric.
- Tape in place to secure.



Step 5

- Turn the hoop over and place the fabric, right side up, completely covering the placement stitch.
- Carefully tape to secure. Avoid pushing too hard on the stabilizer to prevent it from dislodging from the hoop.
- Return the hoop to the machine.



Step 6

• Stitch Machine Step 2, Cut Line and Tackdown.





Step 7

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Trim the excess fabric as close to the cut line stitching as possible.



Step 8

• Turn the hoop over and trim the excess fabric as close to the cut line stitching as possible.





Step 9

- Return the hoop to the machine and stitch the remaining steps per the thread chart.
- Remember to match the bobbin thread to the upper thread for all colors.







Step 10

- When the design is complete, remove the project from the hoop and trim the stabilizer 1/4" 1/2" outside the design.
- Rinse each piece in warm running water until the design is only slightly tacky.
- Place right side down on a non-stick surface to dry. Parchment paper or a cooling rack work well to prevent curling. Dry completely.
- Once dry, press right side down on a Perfect Embroidery Press Cloth.



ASSEMBLY TREES



Step 11

- Choose the tree upper and corresponding bottom style.
- The Tree Section 1 FSA (51257-14) with the open end on the upper half is the tree bottom.
- The Tree Section 2 FSA (51257-15) with the open end on the lower half is the tree top.



Step 12

• Slide the tree top (51257-15) into the open end of the lower part of the tree (51257-14).





GENERAL FREESTANDING LACE GUIDE



Stabilizer

- OESD AguaMesh
- OESD BadgeMaster

Notion/Tools

- 80/12 Embroidery Ballpoint Titanium needle for extended needle life
- OESD Alligator Clamps
- OESD Button Clips
- OESD Perfect Point and Press Tool

Isacord Thread Colors

- All OESD designs are digitized with Isacord 40
 wt. polyester thread as the top thread and in
 the bobbin.
- Refer to the thread chart for color specifications.
- Match bobbin thread color to the top thread.

Instructions

Step 1 - Hoop

For FSL structures, hoop one layer of OESD AquaMesh and one layer of OESD BadgeMaster. BadgeMaster contains more starch so, combined with the AquaMesh, the lace is more rigid.

For other FSL, where a softer lace is desired, hoop two layers of AquaMesh.

Step 2 - Embroider

Stitch the design per the thread chart with matching thread in the bobbin at each color change.

When complete, remove from the hoop and trim away excess stabilizer about 1/4"-1/2" from the stitching.

Step 3 - Rinse

Rinse remaining stabilizer out in warm running water.

For stiffer lace and FSL structures, DO NOT rinse away all of the stabilizer. The lace should be just slightly tacky.

For softer lace, rinse until all traces of the stabilizer is removed.

Step 4 - Dry

Lay right side down flat on a non-stick surface, such as a cookie rack, parchment paper or Teflon sheet. This minimizes the tendency for the lace to curl.

Let the pieces dry completely before proceeding with any assembly.

Step 5 - Press

Once completely dry, press right side down on a OESD Perfect Embroidery Press Cloth.

Step 6 - Assemble Structure

Note: Specific assembly instructions for a design/collection may be found in the thread chart pdf following the individual design color charts.

Lace must be COMPLETELY DRY before assembly. Wetting the buttonettes or eyelets to assemble is not recommended and may result in them stretching and coming "unbuttoned" when dry.

Use a pair of OESD Alligator Clamps to insert the buttonettes into the eyelets. Insert the tip of the OESD Alligator Clamps into the eyelet, grasp the buttonette and pull through the eyelet. Alternatively, use a stiletto or tweezers to push the buttonette through the eyelet.

Helpful Tips

Limp Lace

If the design is not stiff enough, press the lace pieces on the wrong side while applying spray starch. After ironing, spray again with starch and allow to dry completely. This will stiffen the lace pieces nicely and aid in construction. Or easily re-stiffen by diluting some stabilizer scraps in water (or use liquid starch) and dipping the item in the solution. Lay flat to dry.

Eyelets Too Small

If any of the eyelets appear closed or too small to penetrate with Alligator Clamps, they may be stretched by inserting the small end of the OESD Perfect Point and Press Tool into the eyelet opening and stretching it open wide enough to accommodate the OESD Alligator Clamps.

Button Clips

During the assembly process, some structures pull on buttonettes that have already been inserted and could pull them out altogether. Putting a Button Clip on the assembled buttonette will keep it in position during the assembly process. Remove the Button Clips when the assembly is complete.

Alternative Construction Option


In some cases, the buttonettes may be pulled to the inside of a project, instead of being visible on the outside.

Insert the OESD Alligator Clamps through the eyelet from the wrong, or inside, of the lace and grasp the corresponding buttonette. Pull the buttonette to the wrong side of the lace.

Pulling the buttonettes to the inside may cause stress on the ones already done. Button clips may be place on the completed buttonette(s) to prevent them from pulling out of the eyelet.

PUNCH TOOL GUIDES











ATTENTION

When printing this document, any page scaling or page fitting options in your print dialog box must be turned OFF or set to NONE so that your files will print out at their actual size. Images not printed at actual size will not function as intended.




TO SAVE PAPER


Only print the desired image by navigating to the image's page, go to File > Print and select "Current page" in the print dialog box. Repeat for each desired image.

















scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing











Print at 100%. No scaling. This box measures 1"x 1". Use the box as an accuracy guide when printing templates.




51257-13






























RESEA TRANSPORTED TO THE PROPERTY OF THE PROPE

Print at 100%. No scaling. This box measures 1"x 1". Use the box as an accuracy guide when printing templates.



51257-13



