



#51280
1 DESIGN

Freestanding Cookie Cabin



It is a violation of Copyright law to make and distribute copies of electronic designs or artwork.
Electronic designs are licensed to the original purchaser for use at one location. ©2022 OESD, LLC. All rights reserved.

MATERIALS



Isacord Thread Colors

0015 White - 2 Spools
1141 Tan
1805 Strawberry

2560 Azalea Pink
5440 Mint
5515 Kelly

*** Project instructions included after design list.**

Note: One spool of 1000 meter thread is adequate for the project unless otherwise noted.

Table of Contents

Interactive Menu

Click to Navigate

Designs	03
Collection Supplies	11
Summary	12
Embroidery	13
Freestanding Lace Guide	23
Punch Tool Guide	24
Printing Instructions	25
Applique Patterns	26
Mirrored Patterns	32

DESIGNS



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

FABRIC REQUIRED



51280-01 Back Wall FSA

Size Inches: 5.49 X 4.51 in. Size mm: 139.5 X 114.5 mm Stitch Count: 32676 St.

- 1. Brown Fabric Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. Red Fabric Placement Stitch 0015
- 4. Cut Line and Tackdown 0015
- 5. White Lace and Detail 0015
- 6. Tan Detail 1141
- 7. Pink Lace and Detail 2560
- 8. Red Lace and Detail 1805
- 9. Mint Lace and Detail 5440
- 10. Green Lace and Detail 5515
- 11. Cover Stitch and Lace Detail 0015

FABRIC REQUIRED



51280-02 Left Wall FSA

Size Inches: 4.49 X 4.80 in. Size mm: 114.0 X 122.0 mm Stitch Count: 38179 St.


- 1. Brown Fabric Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. White Lace and Detail 0015
- 4. Tan Detail 1141
- 5. Pink Lace and Detail 2560
- 6. Mint Lace and Detail 5440
- 7. Green Lace and Detail 5515
- 8. Red Lace and Detail 1805
- 9. Cover Stitch and Lace Detail 0015

DESIGNS



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

FABRIC REQUIRED



51280-03 Front Wall FSA

Size Inches: Size mm: Stitch Count:
5.49 X 4.34 in. 139.5 X 110.2 mm 27376 St.

- 1. Brown Fabric Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. White Lace and Detail 0015
- 4. Tan Detail 1141
- 5. Pink Lace and Detail 2560
- 6. Red Lace and Detail 1805
- 7. Mint Lace and Detail 5440
- 8. Green Detail 5515
- 9. Cover Stitch and Lace Detail 0015

FABRIC REQUIRED



51280-04 Right Wall FSA

Size Inches: Size mm: Stitch Count:
4.49 X 5.04 in. 114.0 X 127.9 mm 37392 St.

- 1. Brown Fabric Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. White Lace and Detail 0015
- 4. Tan Detail 1141
- 5. Pink Lace and Detail 2560
- 6. Mint Lace and Detail 5440
- 7. Green Lace and Detail 5515
- 8. Red Lace and Detail 1805
- 9. Cover Stitch and Lace Detail 0015

DESIGNS



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

FABRIC REQUIRED

51280-05 Front Door FSA



Size Inches: Size mm: Stitch Count:
3.49 X 5.30 in. **88.7 X 134.7 mm** **21126 St.**

- 1. Brown Fabric Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. Red Fabric Placement Stitch 0015
- 4. Cut Line and Tackdown 0015
- 5. White Lace and Detail 0015
- 6. Tan Detail 1141
- 7. Pink Lace and Detail 2560
- 8. Red Lace and Detail 1805
- 9. Green Lace and Detail 5515
- 10. Mint Lace and Detail 5440
- 11. Cover Stitch and Lace Detail 0015

51280-06 Front Door Roof FSL

Size Inches: Size mm: Stitch Count:
0.96 X 3.76 in. **24.4 X 95.5 mm** **7539 St.**

- 1. Single Color Design 0015



DESIGNS



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

51280-07 Front Door Snow FSL

Size Inches: Size mm: Stitch Count:
1.67 X 2.62 in. 42.4 X 66.5 mm 5835 St.

- 1. Single Color Design..... 0015




FABRIC REQUIRED

51280-08 Attic Floor FSA

Size Inches: Size mm: Stitch Count:
5.21 X 4.86 in. 132.4 X 123.5 mm 12880 St.

- 1. Brown Fabric Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. Cover Stitch and Detail..... 0015




DESIGNS



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

FABRIC REQUIRED



51280-09 Foundation FSA

Size Inches: Size mm: Stitch Count:
5.27 X 4.79 in. 133.9 X 121.8 mm 12069 St.

- 1. Brown Fabric Placement Stitch 1141
- 2. Cut Line and Tackdown 1141
- 3. Tan Detail 1141
- 4. Cover Stitch and Lace Detail 0015

FABRIC REQUIRED



51280-10 Roof 1 FSA

Size Inches: Size mm: Stitch Count:
6.51 X 4.62 in. 165.4 X 117.5 mm 42150 St.

- 1. Brown Fabric Placement Stitch 1141
- 2. Cut Line and Tackdown 1141
- 3. Tan Detail 1141
- 4. White Lace and Detail 0015
- 5. Mint Lace and Detail 5440
- 6. Green Lace and Detail 5515
- 7. Red Lace and Detail 1805
- 8. Pink Detail 2560
- 9. Cover Stitch and Lace Detail 0015

DESIGNS



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

FABRIC REQUIRED

51280-11 Roof 2 FSA

Size Inches: Size mm: Stitch Count:
6.51 X 4.62 in. 165.4 X 117.5 mm 44698 St.

- 1. Brown Fabric Placement Stitch 1141
- 2. Cut Line and Tackdown 1141
- 3. Tan Detail 1141
- 4. White Lace and Detail 0015
- 5. Pink Lace and Detail 2560
- 6. Red Lace and Detail 1805
- 7. Mint Lace and Detail 5440
- 8. Green Detail 5515
- 9. Cover Stitch and Lace Detail 0015



FABRIC REQUIRED

51280-12 Front Gable FSA

Size Inches: Size mm: Stitch Count:
3.58 X 5.08 in. 91.0 X 128.9 mm 17841 St.

- 1. Brown Fabric Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. White Detail 0015
- 4. Tan Detail 1141
- 5. Pink Lace and Detail 2560
- 6. Mint Lace and Detail 5440
- 7. Green Lace and Detail 5515
- 8. Red Detail 1805
- 9. Cover Stitch and Lace Detail 0015



DESIGNS



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

FABRIC REQUIRED

51280-13 Back Gable FSA

Size Inches:	Size mm:	Stitch Count:
3.58 X 5.08 in.	91.0 X 128.9 mm	18081 St.


- 1. Brown Fabric Placement Stitch 0015
- 2. Cut Line and Tackdown 0015
- 3. White Detail 0015
- 4. Tan Detail 1141
- 5. Pink Lace and Detail 2560
- 6. Red Lace and Detail 1805
- 7. Mint Detail 5440
- 8. Cover Stitch and Lace Detail 0015



51280-14 Roof Snow 1 FSL

Size Inches:	Size mm:	Stitch Count:
5.69 X 3.78 in.	144.6 X 95.9 mm	15436 St.

- 1. White Lace and Detail 0015
- 2. Red Lace Detail 1805
- 3. Mint Lace Detail 5440
- 4. Pink Lace Detail 2560




DESIGNS



Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.

51280-15 Roof Snow 2 FSL

Size Inches: Size mm: Stitch Count:
5.69 X 3.77 in. 144.6 X 95.7 mm 15398 St.



- 1. White Lace and Detail 0015
- 2. Red Lace Detail 1805
- 3. Mint Lace Detail 5440
- 4. Pink Lace Detail 2560

MATERIALS



Stabilizers

- OESD AquaMesh WashAway
- OESD BadgeMaster WashAway
- OESD StabilStick CutAway

Fabrics/Textiles

- Brown quilter's cotton 1/4 yard
- Red quilter's cotton 5" x 5"
- **Note:** Fabric sizes are estimates and may result in overage.

Notion & Tools

- OESD Alligator Clamps
- OESD Button Clips
- OESD Expert Embroidery Tape WashAway
- OESD Expert Embroidery Tape TearAway
- OESD Perfect Punch Tool
- OESD Perfect Embroidery Press Cloth
- Embroidery Needle Sharp 75/11

Isacord Thread Colors

- Per thread chart
- Match the bobbin thread to the upper thread.

SUMMARY



Completed Size: 7.25" H x 4.25" W x 5.5" D

51280-01



Requires 1 Design

51280-02



Requires 1 Design

51280-03



Requires 1 Design

51280-04



Requires 1 Design

51280-05




Requires 1 Design

51280-06




Requires 1 Design

51280-07




Requires 1 Design

51280-08



Requires 1 Design

51280-09



Requires 1 Design

51280-10



Requires 1 Design

51280-11



Requires 1 Design

51280-12




Requires 1 Design

51280-13




Requires 1 Design

51280-14



Requires 1 Design

51280-15



Requires 1 Design

EMBROIDERY



General Instructions

The freestanding applique instructions, included in the collection, are general instructions. For demonstration purposes, a sample design that best demonstrates the technique is shown. Fabric and thread requirements will vary by design, but the general technique is the same.

All designs are stitched with matching thread, top and bobbin.

Note: Some thread colors in instructions have been changed or digitally enhanced for better visibility.

□ Step 1

- Hoop one layer of AquaMesh and one layer of BadgeMaster for all designs.



□ Step 2

- Adhere two layers of StabilStick CutAway to the wrong side of all applique fabrics, to provide stiffness to the finished structure.
- Cut the prepared applique fabrics 1/4" -1/2" larger than the templates that are included at the end of the instructions.




EMBROIDERY




□ Step 3

- Load selected design into the machine.
- Example design is 51280-05.
- Thread the machine per the thread chart.
- Place hoop on the machine.
- Stitch Machine Step 1, Brown Fabric Placement Stitch.




□ Step 4

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Completely cover the placement stitch with the prepared fabric.
- Tape in place to secure.



□ Step 5

- Return the hoop to the machine.
- Stitch Machine Step 2, Cut Line and Tackdown.



EMBROIDERY




□ Step 6

- Remove the hoop from the machine, but NOT the project from the hoop.
- Trim the excess fabric as close to the cut line as possible. If the outermost stitches (cut line) are cut, the inner stitches (tackdown) will hold the applique in place.
- Tip: If the stabilizer is cut or a hole is created while trimming the fabric, use OESD Expert Embroidery Tape WashAway as a patch.




□ Step 7

- Return the hoop to the machine.
- Stitch Machine Step 3, Red Placement Stitch.



□ Step 8

- Remove the hoop from the machine, but NOT the project from the hoop.
- Place the hoop on a flat surface.
- Completely cover the placement stitch with the prepared fabric.
- Tape in place to secure.



EMBROIDERY



□ Step 9

- Return the hoop to the machine.
- Stitch Machine Step 3, Cut Line and Tackdown.



□ Step 10

- Remove the hoop from the machine, but NOT the project from the hoop.
- Trim the excess fabric as close to the cut line as possible.



□ Step 11

- Return the hoop to the machine.
- Stitch the remaining machine steps per the thread chart, with matching bobbin thread.



EMBROIDERY




□ Step 12

- When the design is complete, remove the project from the hoop and trim the stabilizer 1/4" - 1/2" outside the design.



□ Step 13

- Rinse each piece under warm running water until the design is only slightly tacky.



□ Step 14


- Lay right side down on a non-stick surface to dry. Parchment paper or a cooling rack work well to prevent curling. Let dry completely.
- Once dry, press right side down on a Perfect Embroidery Press Cloth.

ASSEMBLY



Step 15

- Before assembly, use a craft knife to cut through all the layers of the tab entries.
- Use the OESD Punch Tool with the 3mm attachment to create the eyelets indicated on the punch tool guide on page 24.
- **Tip:** Take care to not cut the satin stitching.



Step 16

- Line up the wall pieces 51280-01, 51280-02, 51280-03, 51280-04 to connect.
- Thread the sewing machine with matching thread in the top and bobbin.
- Stitch together using a multi-step zigzag stitch (also known as a serpentine stitch).
- Backstitch at the beginning and end to secure.
- Trim thread tails.
- Fold and press into shape.



Step 17

- Line up roof pieces 51280-10 and 51280-11 to connect.
- Stitch together using a multi-step zigzag.
- Backstitch at the beginning and end to secure.
- Trim thread tails.
- Set aside.



ASSEMBLY




Step 18

- Match the eyelets and buttonettes on walls (51280-01 to 51280-04).
- Use Alligator Clamps to pull each buttonette through the corresponding eyelet, using button clips to temporarily hold them in place, as needed.




Step 19

- Match the eyelets and lock tabs of the Attic Floor FSA (51280-08) to the base structure.
- Pull tabs and buttonettes through the corresponding openings.



Step 20

- Match the eyelets of the Front Door Roof FSL (51280-06) to Front Door FSA (51280-05). Position the Front Door Roof FSL so the buttonettes are facing away from the locking tabs.



ASSEMBLY



Step 21

- Match the eyelets of the Front Door Snow FSL (51280-07) to the buttonettes of the Door Roof FSL (51280-06).




Step 22

- Match the locking tabs of the Front Door FSA (51280-05) into the tab entries of the Front Wall FSA (51280-03).
- Tip:** Pull the lock tabs from the bottom of the structure.



Step 23

- Match the house structure eyelets to the buttonettes on Foundation FSA (51280-09).
- Pull each buttonette through the corresponding eyelet, using button clips to temporarily hold them in place, as needed.




ASSEMBLY





Step 24

- Match the roof eyelets to the Front Gable FSA (51280-12) and Back Gable FSA (51280-13).



Step 25

- Match the roof snow eyelets to the buttonettes on both sides of the roof assembly (51280-14 & 51280-15).
- Pull each buttonette through the corresponding eyelet.



Step 26

- Place the roof on the house structure.
- Note: Roof is not connected to the structure.
- Tip: Place a tea light on the Attic Floor to illuminate the roof designs.



FINISHING TOUCHES



□ Step 27

- Add tealights or pixie lights to create a glow.



GENERAL FREESTANDING LACE GUIDE



Stabilizer

- OESD AquaMesh
- OESD BadgeMaster

Notion/Tools

- 80/12 Embroidery Ballpoint Titanium needle for extended needle life
- OESD Alligator Clamps
- OESD Button Clips
- OESD Perfect Point and Press Tool

Isacord Thread Colors

- All OESD designs are digitized with Isacord 40 wt. polyester thread as the top thread and in the bobbin.
- Refer to the thread chart for color specifications.
- Match bobbin thread color to the top thread.

Instructions

Step 1 - Hoop

For FSL structures, hoop one layer of OESD AquaMesh and one layer of OESD BadgeMaster. BadgeMaster contains more starch so, combined with the AquaMesh, the lace is more rigid.

For other FSL, where a softer lace is desired, hoop two layers of AquaMesh.

Step 2 - Embroider

Stitch the design per the thread chart with matching thread in the bobbin at each color change.

When complete, remove from the hoop and trim away excess stabilizer about 1/4"-1/2" from the stitching.

Step 3 - Rinse

Rinse remaining stabilizer out in warm running water.

For stiffer lace and FSL structures, DO NOT rinse away all of the stabilizer. The lace should be just slightly tacky.

For softer lace, rinse until all traces of the stabilizer is removed.

Step 4 - Dry

Lay right side down flat on a non-stick surface, such as a cookie rack, parchment paper or Teflon sheet. This minimizes the tendency for the lace to curl.

Let the pieces dry completely before proceeding with any assembly.

Step 5 - Press

Once completely dry, press right side down on a OESD Perfect Embroidery Press Cloth.

Step 6 - Assemble Structure

Note: Specific assembly instructions for a design/collection may be found in the thread chart pdf following the individual design color charts.

Lace must be COMPLETELY DRY before assembly. Wetting the buttonettes or eyelets to assemble is not recommended and may result in them stretching and coming "unbuttoned" when dry.

Use a pair of OESD Alligator Clamps to insert the buttonettes into the eyelets. Insert the tip of the OESD Alligator Clamps into the eyelet, grasp the buttonette and pull through the eyelet. Alternatively, use a stiletto or tweezers to push the buttonette through the eyelet.

Helpful Tips

Limp Lace

If the design is not stiff enough, press the lace pieces on the wrong side while applying spray starch. After ironing, spray again with starch and allow to dry completely. This will stiffen the lace pieces nicely and aid in construction. Or easily re-stiffen by diluting some stabilizer scraps in water (or use liquid starch) and dipping the item in the solution. Lay flat to dry.

Eyelets Too Small

If any of the eyelets appear closed or too small to penetrate with Alligator Clamps, they may be stretched by inserting the small end of the OESD Perfect Point and Press Tool into the eyelet opening and stretching it open wide enough to accommodate the OESD Alligator Clamps.

Button Clips

During the assembly process, some structures pull on buttonettes that have already been inserted and could pull them out altogether. Putting a Button Clip on the assembled buttonette will keep it in position during the assembly process. Remove the Button Clips when the assembly is complete.

Alternative Construction Option

In some cases, the buttonettes may be pulled to the inside of a project, instead of being visible on the outside.


Insert the OESD Alligator Clamps through the eyelet from the wrong, or inside, of the lace and grasp the corresponding buttonette. Pull the buttonette to the wrong side of the lace.

Pulling the buttonettes to the inside may cause stress on the ones already done. Button clips may be placed on the completed buttonette(s) to prevent them from pulling out of the eyelet.


PUNCH TOOL GUIDES



51280-03



51280-08



● = 2 MM

● = 3 MM

● = 4 MM

CRAFT KNIFE




PRINTING INSTRUCTIONS




ATTENTION

When printing this document, any page scaling or page fitting options in your print dialog box must be turned OFF or set to NONE so that your files will print out at their actual size. Images not printed at actual size will not function as intended.



TO SAVE PAPER




Only print the desired image by navigating to the image's page, go to File > Print and select "Current page" in the print dialog box. Repeat for each desired image.



APPLIQUE PATTERNS







Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



APPLIQUE PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



APPLIQUE PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.

51280-08

APPLIQUE PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



APPLIQUE PATTERNS



51280-09






Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.

APPLIQUE PATTERNS






Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



MIRRORED PATTERNS






Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



MIRRORED PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.



MIRRORED PATTERNS




Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.

51280-08
Mirrored

MIRRORED PATTERNS




51280-09
Mirrored



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.

MIRRORED PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.

MIRRORED PATTERNS



Print at 100%. No scaling. This box measures 1" x 1". Use the box as an accuracy guide when printing templates.

